


 **GOULDS PUMPS**

# Installation, Operation, and Maintenance Manual

3298 Family



**ITT**



# Table of Contents

<b>1 Introduction and Safety .....</b>	<b>4</b>
1.1 Introduction.....	4
1.1.1 Requesting other information .....	4
1.2 Safety .....	4
1.2.1 Safety terminology and symbols .....	5
1.2.2 Environmental safety.....	6
1.2.3 User safety .....	7
1.2.4 Ex-approved products .....	8
1.2.5 Monitoring equipment.....	13
1.3 Product warranty .....	13
<b>2 Transportation and Storage.....</b>	<b>14</b>
2.1 Inspect the delivery .....	14
2.1.1 Inspect the package .....	14
2.1.2 Inspect the unit.....	14
2.2 Transportation guidelines .....	14
2.2.1 Precautions .....	14
2.2.2 Pump handling .....	14
2.2.3 Lifting methods.....	14
2.3 Storage guidelines.....	16
2.3.1 Pump storage requirements.....	16
<b>3 Product Description .....</b>	<b>18</b>
3.1 General description .....	18
3.2 Nameplate information .....	19
<b>4 Installation.....</b>	<b>23</b>
4.1 Pre-installation.....	23
4.1.1 Pump location guidelines .....	23
4.1.2 Foundation requirements .....	24
4.2 Baseplate-mounting procedures .....	25
4.2.1 Prepare the baseplate for mounting.....	25
4.2.2 Install the baseplate using shims or wedges.....	25
4.2.3 Install the baseplate using jackscrews .....	26
4.2.4 Baseplate-leveling worksheet .....	30
4.3 Pump-to-driver alignment.....	31
4.3.1 Alignment checks .....	31
4.3.2 Permitted indicator values for alignment checks.....	32
4.3.3 Alignment measurement guidelines .....	32
4.3.4 Attach the dial indicators for alignment .....	32
4.3.5 Pump-to-driver alignment instructions.....	33
4.4 Grout the baseplate.....	37
4.5 Piping checklists.....	38
4.5.1 Fastening .....	38
4.5.2 General piping checklist .....	38
4.5.3 Suction-piping checklist.....	41
4.5.4 Discharge piping checklist.....	44
4.5.5 Final piping checklist.....	45

<b>5</b>	<b>Commissioning, Startup, Operation, and Shutdown</b>	<b>46</b>
5.1	Preparation for startup	46
5.2	Remove the coupling guard	47
5.3	Check the rotation	49
5.4	Check the rotation - Close Coupled	50
5.5	Couple the pump and driver	50
5.5.1	Install the coupling guard	50
5.6	Bearing lubrication	55
5.6.1	Lubricating oil requirements	55
5.6.2	Acceptable oil for lubricating bearings	56
5.6.3	Lubricate the bearings with oil	56
5.7	Pump priming	57
5.7.1	Prime the pump with the suction supply above the pump	57
5.7.2	Prime the pump with the suction supply below the pump	57
5.7.3	Other methods of priming the pump	58
5.8	Start the pump	58
5.8.1	Minimum continuous recommended flow	59
5.9	Pump operation precautions	60
5.10	Shut down the pump	61
5.11	Make the final alignment of the pump and driver	62
<b>6</b>	<b>Maintenance</b>	<b>63</b>
6.1	Maintenance schedule	63
6.2	Bearing maintenance	64
6.3	Required tools	64
6.4	Disassembly	65
6.4.1	Disassembly precautions	65
6.4.2	Prepare the pump for disassembly	66
6.4.3	Disassemble the close-coupled pump	66
6.4.4	Disassemble the frame-mounted pump	69
6.5	Preassembly inspections	72
6.6	Reassembly	75
6.6.1	Reassembly precautions	75
6.6.2	Reassemble the rotary assembly	76
6.6.3	Reassemble the close-coupled pump	82
6.6.4	Reassemble the frame-mounted pump	83
6.6.5	Complete the reassembly (close-coupled and frame-mounted pumps)	87
6.6.6	Assembly references	88
6.7	Spare parts	94
6.7.1	Repair kits	94
<b>7</b>	<b>Troubleshooting</b>	<b>96</b>
7.1	Operation troubleshooting	96
7.2	Alignment troubleshooting	98
<b>8</b>	<b>Parts List and Cross-Sectionals</b>	<b>99</b>
8.1	3298 XS group close-coupled pump	99
8.2	3298 S group frame-mounted pump	101
8.3	3298 S group close-coupled pump	103
8.4	3298 M group frame-mounted pump	105
8.5	3298 M group close-coupled pump	107

---

8.6	3298 L group frame-mounted pump .....	108
8.7	3298 L group close-coupled pump .....	111
8.8	SP3298 S group frame-mounted pump in sizes 1 x 1-1/2 - 6 .....	113
8.9	SP3298 S group close-coupled pump in sizes 1 x 1-1/2 - 6.....	115
8.10	V3298 close-coupled S group pump in sizes 1-1/2 x 2 - 6, 2 x 3 - 6, 1-1/2 x 2 - 8 and M group size 1-1/2 x 2 - 10.....	118
8.11	Interchangeability drawings .....	121
8.12	Hydraulic coverage charts.....	127
<b>9</b>	<b>Other Relevant Documentation or Manuals.....</b>	<b>131</b>
9.1	For additional documentation.....	131
<b>10</b>	<b>Local ITT Contacts .....</b>	<b>132</b>
10.1	Regional offices.....	132

# 1 Introduction and Safety

## 1.1 Introduction

### Purpose of this manual

The purpose of this manual is to provide necessary information for:

- Installation
- Operation
- Maintenance



### **CAUTION:**

Failure to observe the instructions contained in this manual could result in personal injury and/or property damage, and may void the warranty. Read this manual carefully before installing and using the product.

---

### **NOTICE:**

Save this manual for future reference and keep it readily available.

---

### 1.1.1 Requesting other information

Special versions can be supplied with supplementary instruction leaflets. See the sales contract for any modifications or special version characteristics. For instructions, situations, or events that are not considered in this manual or in the sales documents, please contact the nearest ITT representative.

Always specify the exact product type and serial number when requesting technical information or spare parts.

## 1.2 Safety



### **WARNING:**

- Risk of serious personal injury. Applying heat to impellers, propellers, or their retaining devices can cause trapped liquid to rapidly expand and result in a violent explosion. This manual clearly identifies accepted methods for disassembling units. These methods must be adhered to. Never apply heat to aid in their removal unless explicitly stated in this manual.
- The operator must be aware of the pumpage and take appropriate safety precautions to prevent physical injury.
- Risk of serious injury or death. If any pressure-containing device is over-pressurized, it can explode, rupture, or discharge its contents. It is critical to take all necessary measures to avoid over-pressurization.
- Risk of death, serious personal injury, and property damage. Installing, operating, or maintaining the unit using any method not prescribed in this manual is prohibited. Prohibited methods include any modification to the equipment or use of parts not provided by ITT. If there is any uncertainty regarding the appropriate use of the equipment, please contact an ITT representative before proceeding.

- If the pump or motor is damaged or leaking, electric shock, fire, explosion, liberation of toxic fumes, physical harm, or environmental damage may result. Do not operate the unit until the problem has been corrected or repaired.
- Risk of serious personal injury or property damage. Dry running may cause rotating parts within the pump to seize to non-moving parts. Do not run dry.
- Risk of death, serious personal injury, and property damage. Heat and pressure buildup can cause explosion, rupture, and discharge of pumpage. Never operate the pump with suction and/or discharge valves closed.
- Running a pump without safety devices exposes operators to risk of serious personal injury or death. Never operate a unit unless appropriate safety devices (guards, etc.) are properly installed. See specific information about safety devices in other sections of this manual.

**CAUTION:**

- Risk of injury and/or property damage. Operating a pump in an inappropriate application can cause over pressurization, overheating, and/or unstable operation. Do not change the service application without the approval of an authorized ITT representative.

**WARNING:**

This product contains Carbon Black a chemical known to the State of California to cause cancer. For more information go to [www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

## 1.2.1 Safety terminology and symbols

### About safety messages

It is extremely important that you read, understand, and follow the safety messages and regulations carefully before handling the product. They are published to help prevent these hazards:

- Personal accidents and health problems
- Damage to the product
- Product malfunction

### Hazard levels

Hazard level	Indication
<b>DANGER:</b>	A hazardous situation which, if not avoided, will result in death or serious injury
<b>WARNING:</b>	A hazardous situation which, if not avoided, could result in death or serious injury
<b>CAUTION:</b>	A hazardous situation which, if not avoided, could result in minor or moderate injury
<b>NOTICE:</b>	<ul style="list-style-type: none"> <li>• A potential situation which, if not avoided, could result in undesirable conditions</li> <li>• A practice not related to personal injury</li> </ul>

### Hazard categories

Hazard categories can either fall under hazard levels or let specific symbols replace the ordinary hazard level symbols.

Electrical hazards are indicated by the following specific symbol:



#### **ELECTRICAL HAZARD:**

These are examples of other categories that can occur. They fall under the ordinary hazard levels and may use complementing symbols:

- Crush hazard
- Cutting hazard
- Arc flash hazard

### 1.2.1.1 The Ex symbol

The Ex symbol indicates safety regulations for Ex-approved products when used in atmospheres that are potentially explosive or flammable.



### 1.2.2 Environmental safety

#### The work area

Always keep the station clean to avoid and/or discover emissions.

#### Waste and emissions regulations

Observe these safety regulations regarding waste and emissions:

- Appropriately dispose of all waste.
- Handle and dispose of the processed liquid in compliance with applicable environmental regulations.
- Clean up all spills in accordance with safety and environmental procedures.
- Report all environmental emissions to the appropriate authorities.



---

#### **WARNING:**

If the product has been contaminated in any way, such as from toxic chemicals or nuclear radiation, do NOT send the product to ITT until it has been properly decontaminated and advise ITT of these conditions before returning.

---

#### Electrical installation

For electrical installation recycling requirements, consult your local electric utility.

### 1.2.2.1 Recycling guidelines

Always follow local laws and regulations regarding recycling.



---

## 1.2.3 User safety

### General safety rules

These safety rules apply:

- Always keep the work area clean.
- Pay attention to the risks presented by gas and vapors in the work area.
- Avoid all electrical dangers. Pay attention to the risks of electric shock or arc flash hazards.
- Always bear in mind the risk of drowning, electrical accidents, and burn injuries.

### Safety equipment

Use safety equipment according to the company regulations. Use this safety equipment within the work area:

- Hardhat
- Safety goggles, preferably with side shields
- Protective shoes
- Protective gloves
- Gas mask
- Hearing protection
- First-aid kit
- Safety devices

### Electrical connections

Electrical connections must be made by certified electricians in compliance with all international, national, state, and local regulations. For more information about requirements, see sections dealing specifically with electrical connections.

### Noise



#### **WARNING:**

Sound pressure levels may exceed 80 dbA in operating process plants. Clear visual warnings or other indicators should be available to those entering an area with unsafe noise levels. Personnel should wear appropriate hearing protection when working on or around any equipment, including pumps. Consider limiting personnel's exposure time to noise or, where possible, enclosing equipment to reduce noise. Local law may provide specific guidance regarding exposure of personnel to noise and when noise exposure reduction is required.

---

### Temperature



#### **WARNING:**

Equipment and piping surfaces may exceed 130°F (54°C) in operating process plants. Clear visual warnings or other indicators should alert personnel to surfaces that may reach a potentially unsafe temperature. Do not touch hot surfaces. Allow pumps operating at a high temperature to cool sufficiently before performing maintenance. If touching a hot surface cannot be avoided, personnel should wear appropriate gloves, clothing, and other protective gear as necessary. Local law may provide specific guidance regarding exposure of personnel to unsafe temperatures.

---

### 1.2.3.1 Magnetic precautions



**WARNING:**

Magnetic drive pumps contain very strong magnets that can pose health risks. Always observe these guidelines:

- Avoid working with, being in proximity of, or handling the magnets contained in this pump if you have any of these conditions:
  - An artificial cardiac pacemaker
  - An implanted defibrillator
  - A metallic prosthetic heart valve
  - Internal wound clips, from surgery
  - Prosthetic joints
  - Metallic wiring
  - Any other type of metallic, prosthetic device
- Individuals who have had any surgery, especially to the chest or head, and do not know if metallic clips were surgically implanted need to avoid work on this unit unless their physician can confirm that no metallic devices exist.

### 1.2.3.2 Wash the skin and eyes

1. Follow these procedures for chemicals or hazardous fluids that have come into contact with your eyes or your skin:

Condition	Action
Chemicals or hazardous fluids in eyes	<ol style="list-style-type: none"> <li>1. Hold your eyelids apart forcibly with your fingers.</li> <li>2. Rinse the eyes with eyewash or running water for at least 15 minutes.</li> <li>3. Seek medical attention.</li> </ol>
Chemicals or hazardous fluids on skin	<ol style="list-style-type: none"> <li>1. Remove contaminated clothing.</li> <li>2. Wash the skin with soap and water for at least 1 minute.</li> <li>3. Seek medical attention, if necessary.</li> </ol>

### 1.2.4 Ex-approved products

Special care must be taken in potentially explosive environments to ensure that the equipment is properly maintained. This includes but is not limited to:



Follow these special handling instructions if you have an Ex-approved unit.

**Personnel requirements**

These are the personnel requirements for Ex-approved products in potentially explosive atmospheres:

- All work on the product must be carried out by certified electricians and ITT-authorized mechanics. Special rules apply to installations in explosive atmospheres.
- All users must know about the risks of electric current and the chemical and physical characteristics of the gas, the vapor, or both present in hazardous areas.

- Any maintenance for Ex-approved products must conform to international and national standards (for example, EN 60079-17).

ITT disclaims all responsibility for work done by untrained and unauthorized personnel.

### Product and product handling requirements

These are the product and product handling requirements for Ex-approved products in potentially explosive atmospheres:

- Only use the product in accordance with the approved motor data.
- The Ex-approved product must never run dry during normal operation. Dry running during service and inspection is only permitted outside the classified area.
- Before you start work on the product, make sure that the product and the control panel are isolated from the power supply and the control circuit, so they cannot be energized.
- Do not open the product while it is energized or in an explosive gas atmosphere.
- Make sure that thermal contacts are connected to a protection circuit according to the approval classification of the product, and that they are in use.
- Intrinsically safe circuits are normally required for the automatic level-control system by the level regulator if mounted in zone 0.
- The yield stress of fasteners must be in accordance with the approval drawing and the product specification.
- Do not modify the equipment without approval from an authorized ITT representative.
- Only use parts that are provided by an authorized ITT representative.

### Description of Ex-Directives

The Ex-directives are a specification enforced in Europe and the United Kingdom for electrical and non-electrical equipment installed in those locations. Ex-directives deal with the control of potentially explosive atmospheres and the standards of equipment and protective systems used within these atmospheres. The relevance of the Ex-requirements is not limited to Europe or the UK. You can apply these guidelines to equipment installed in any potentially explosive atmosphere.

### Guidelines for compliance

Compliance is fulfilled only when you operate the unit within its intended use. Do not change the conditions of the service without the approval of an ITT representative. When you install or maintain explosion proof products, always comply with the directive and applicable standards (for example, IEC/EN 60079-14).

1. Monitoring the pump frame liquid end temperature.
2. Maintaining proper bearing lubrication.
3. Ensuring that the pump is operated in the intended hydraulic range.

The Ex conformance is only applicable when the pump unit is operated within its intended use. Operating, installing or maintaining the pump unit in any way that is not covered in the Instruction, Operation, and Maintenance manual (IOM) can cause serious personal injury or damage to the equipment. This includes any modification to the equipment or use of parts not provided by ITT Goulds Pumps. If there is any question regarding the intended use of the equipment, please contact an ITT Goulds representative before proceeding.

Current IOMs are available at <https://www.gouldspumps.com/en-US/Tools-and-Resources/Literature/IOMs/> or from your local ITT Goulds Pumps Sales representative.

All pumping unit (pump, seal, coupling, motor and pump accessories) certified for use in an Ex classified environment, are identified by an Ex tag secured to the pump or the baseplate on which it is mounted. A typical tag would look like this:

If applicable, your pump may have either a CE Ex (ATEX) tag or UKCA Ex tag affixed to the pump. See the Safety section for a description of the symbols and codes. Typical nameplate only shown below, the actual area classification may be different.



Figure 1: Typical Ex nameplate



Figure 2: Typical UKCA Ex nameplate

Table 1: Temperature class definitions

Code	Maximum permissible surface temperature in °C   °F	Maximum permissible liquid temperature in °C   °F
T1	440   824	372   700
T2	290   554	267   513
T3	195   383	172   342
T4	130   266	107   225
T5	Option not available	Option not available
T6	Option not available	Option not available

\* Maximum liquid temperature may be limited by the pump model and order specific options. [Table 1: Temperature class definitions on page 10](#) is for the purpose of determining T'x' code for Ex applications with liquid temperatures exceeding 107°C | 225°F.

The code classification marked on the equipment must be in accordance with the specified area where the equipment will be installed. If it is not, do not operate the equipment and contact your ITT Goulds Pumps sales representative before proceeding.

### Equipment for monitoring

For additional safety, use condition-monitoring devices. Condition-monitoring devices include but are not limited to these devices:



#### WARNING:

- When pumping unit is installed in a potentially explosive atmosphere, the instructions after the Ex symbol must be followed. Personal injury and/or equipment damage may occur if these instructions are not followed. If there is any question regarding these requirements or if the equipment is to be modified, please contact a Goulds representative before proceeding.
- If equipment is to be installed in a potentially explosive atmosphere and these procedures are not followed, personal injury or equipment damage from an explosion may result.
- Particular care must be taken when the electrical power source to the equipment is energized.

- Improper impeller adjustment could cause contact between the rotating and stationary parts, resulting in a spark and heat generation.
- Lock out driver power to prevent electric shock, accidental start-up and physical injury.
- NEVER start pump without proper prime (all models), or proper liquid level in self-priming pumps (Model 3796 and SP3298).
- Equipment that will operate in a potentially explosive environment must be installed in accordance with the following instructions.
- All equipment being installed must be properly grounded to prevent unexpected static electric discharge. This includes ensuring that the PFA lined pumps (Model 3198), ETFE lined pumps (Model 3298, SP3298, V3298), and the non-metallic liquid end pumps (Model NM3196) are pumping fluids that are conductive. If not, a static electric discharge may occur when the pump is drained and disassembled for maintenance purposes.
- All equipment being installed must be properly grounded to prevent unexpected static electric discharge.
- When pumping fluids with conductivity less than 1000 ps/m follow IEC TS 60079 32-1 guidelines.
- Alignment procedures must be followed to prevent unintended contact of rotating parts. Follow coupling manufacturer's installation and operation procedures.
- When installing in a potentially explosive environment, ensure that the motor and accessories are properly certified.
- The impeller clearance setting procedure must be followed. Improperly setting the clearance or not following any of the proper procedures can result in sparks, unexpected heat generation and equipment damage.
- The impeller and wear ring clearance setting procedures must be followed. Improperly setting the clearance or not following any of the proper procedures can result in sparks, unexpected heat generation and equipment damage.
- Service temperature in an Ex classified environment is limited to the area classification specified on the Ex tag affixed to the pump (reference Table 1 in the Safety section for Ex classifications).
- The coupling used in an Ex classified environment must be properly certified.
- The coupling guard used in an Ex classified environment must be constructed from a spark-resistant material.
- Bearings must be lubricated properly in order to prevent excess heat generation, sparks and premature failure.
- The mechanical seal used in an Ex classified environment must be properly certified.
- The mechanical seal must have an appropriate seal flush system. Failure to do so will result in excess heat generation and seal failure.
- Packed stuffing boxes are not allowed in an Ex classified environment.
- Dynamic seals are not allowed in an Ex classified environment.
- Pumps that are not self-priming must be fully primed at all times during operation. The only model lines that are self-priming is the 3796 and SP3298.
- Pumps must be fully primed at all times during operation.
- The preventive maintenance section must be adhered to in order to keep the applicable Ex classification of the equipment. Failure to follow these procedures will void the Ex classification for the equipment. Bearing replacement intervals are given in the specific pump model IOM.
- Inspection intervals should be shortened appropriately if the pumpage is abrasive and/or corrosive, or if the environment is classified as potentially explosive.

- Throughout this section on bearing lubrication, different pumpage temperatures are listed. If the equipment is Ex certified and the listed temperature exceeds the applicable value shown in Table 1 under SAFETY, then that temperature is not valid. Should this situation occur, please consult with your ITT/Goulds representative.
  - Cooling systems, such as those for bearing lubrication, mechanical seal systems, etc., where provided, must be operating properly to prevent excess heat generation, sparks and premature failure.
  - Rotate shaft by hand to ensure it rotates smoothly and there is no rubbing which could lead to excess heat generation, sparks and premature failure.
  - Flange loads from the piping system, including those from thermal expansion of the piping, must not exceed the limits of the pump. Casing deformation can result in contact with rotating parts which can result in excess heat generation, sparks and premature failure.
  - Ensure that pump and systems are free of foreign objects before operating and that objects cannot enter the pump during operation. Foreign objects in the pumpage or piping system can cause blockage of flow which can result in excess heat generation, sparks and premature failure.
  - Do not insulate or allow the bearing housings to accumulate a dust layer as this can result in excess heat generation, sparks and premature failure.
  - Check for magnetism on the pump shaft and demagnetize the shaft if there is any detectable magnetism. Magnetism will attract ferritic objects to the impeller, seals and bearings which can result in excess heat generation, sparks and premature failure.
  - Leakage of process liquid may result in creation of an explosive atmosphere. Ensure the materials of the pump casing, impeller, shaft, sleeves, gaskets and seals are compatible with the process liquid.
  - Leakage of process liquid may result in creation of an explosive atmosphere. Follow all pump and seal assembly procedures.
  - A buildup of gases within the pump, sealing system and or process piping system may result in an explosive environment within the pump or process piping system. Ensure process piping system, pump and sealing system are properly vented prior to operation.
  - Sealing systems that are not self purging or self venting, such as plan 23, require manual venting prior to operation. Failure to do so will result in excess heat generation and seal failure.
  - Do not apply additional paint or coatings to the pump when in an Ex environment. Static electric discharge can be initiated when contacting or rubbing surfaces with excessive coating thickness.
  - Potential electrostatic charging hazard. Do not rub, clean, or blast equipment with dry cloth or dry media.
  - Stray electrical currents may ignite explosive atmospheres. Ensure drives are certified for variable frequency drive operation by the manufacturer.
  - User shall observe necessity of using a safety device, such as a flame arrestor, to prevent flame entering or leaving the pump sump, tank, or barrel when applicable.
  - For variable speed motor applications, the electric motor must be specified with shaft grounding and used with a conductive type coupling suitable for the area classification.
  - In plants or pumps with cathodic corrosion protection, a small current constantly flows through the construction. This is not permissible on the complete pump or partially-assembled machinery without further precautions being taken. ITT should be consulted in this context.
  - Move equipment to a safe/non Ex environment for repairs/adjustments or use spark resistant tools and work methods.
-

---

## 1.2.5 Monitoring equipment

For additional safety, use condition-monitoring devices. Condition-monitoring devices include but are not limited to these devices:

- Pressure gauges
- Flow meters
- Level indicators
- Motor load readings
- Temperature detectors
- Bearing monitors
- Leak detectors
- PumpSmart control system
- Filter

## 1.3 Product warranty

### Coverage

ITT undertakes to remedy faults in products from ITT under these conditions:

- The faults are due to defects in design, materials, or workmanship.
- The faults are reported to an ITT representative within the warranty period.
- The product is used only under the conditions described in this manual.
- The monitoring equipment incorporated in the product is correctly connected and in use.
- All service and repair work is done by ITT-authorized personnel.
- Genuine ITT parts are used.
- Only Ex-approved spare parts and accessories authorized by ITT are used in Ex-approved products.

### Limitations

The warranty does not cover faults caused by these situations:

- Deficient maintenance
- Improper installation
- Modifications or changes to the product and installation made without consulting ITT
- Incorrectly executed repair work
- Normal wear and tear

ITT assumes no liability for these situations:

- Bodily injuries
- Material damages
- Economic losses

### Warranty claim

ITT products are high-quality products with expected reliable operation and long life. However, should the need arise for a warranty claim, then contact your ITT representative.

# 2 Transportation and Storage

## 2.1 Inspect the delivery

### 2.1.1 Inspect the package

1. Inspect the package for damaged or missing items upon delivery.
2. Note any damaged or missing items on the receipt and freight bill.
3. File a claim with the shipping company if anything is out of order.  
If the product has been picked up at a distributor, make a claim directly to the distributor.

### 2.1.2 Inspect the unit

1. Remove packing materials from the product.  
Dispose of all packing materials in accordance with local regulations.
2. Inspect the product to determine if any parts have been damaged or are missing.
3. If applicable, unfasten the product by removing any screws, bolts, or straps.  
For your personal safety, be careful when you handle nails and straps.
4. Contact your sales representative if anything is out of order.

## 2.2 Transportation guidelines

### 2.2.1 Precautions



---

**WARNING:**

- Stay clear of suspended loads.
  - Observe accident prevention regulations in force.
- 

### 2.2.2 Pump handling



---

**WARNING:**

Dropping, rolling or tipping units, or applying other shock loads, can cause property damage and/or personal injury. Ensure that the unit is properly supported and secure during lifting and handling.

---



---

**CAUTION:**

Risk of injury or equipment damage from use of inadequate lifting devices. Ensure lifting devices (such as chains, straps, forklifts, cranes, etc.) are rated to sufficient capacity.

---

### 2.2.3 Lifting methods



---

**WARNING:**



- Risk of serious personal injury or equipment damage. Proper lifting practices are critical to safe transport of heavy equipment. Ensure that practices used are in compliance with all applicable regulations and standards.
-




- Safe lifting points are specifically identified in this manual. It is critical to lift the equipment only at these points. Integral lifting eyes or eye bolts on pump and motor components are intended for use in lifting the individual components only.
- Lifting and handling heavy equipment poses a crush hazard. Use caution during lifting and handling and wear appropriate Personal Protective Equipment (PPE, such as steel-toed shoes, gloves, etc.) at all times. Seek assistance if necessary.


**Table 2: Methods**

Pump type	Lifting method
Bare pump without lifting handles	Use a suitable sling attached properly to solid points like the casing, the flanges, or the frames.
A base-mounted pump	Use slings under the pump casing and the drive unit, or under the base rails.

**Examples****Figure 3: Proper lifting method for a bare pump****Figure 4: Proper lifting method for a pump with a base and driver**



**Figure 5: Proper lifting method for a vertical pump with a driver**



**Figure 6: Proper lifting method for a vertical pump with no driver**

## 2.3 Storage guidelines

### 2.3.1 Pump storage requirements

Storage requirements depend on the amount of time that you store the unit. The normal packaging is designed only to protect the unit during shipping.

Length of time in storage	Storage requirements
Upon receipt/short-term (less than six months)	<ul style="list-style-type: none"> <li>• Store in a covered and dry location.</li> <li>• Store the unit free from dirt and vibrations.</li> </ul>
Long-term (more than six months)	<ul style="list-style-type: none"> <li>• Store in a covered and dry location.</li> <li>• Store the unit free from heat, dirt, and vibrations.</li> </ul>

---

Length of time in storage	Storage requirements
	<ul style="list-style-type: none"><li data-bbox="721 226 1476 262">• Rotate the shaft by hand several times at least every three months.</li></ul>

Treat bearing and machined surfaces so that they are well preserved. Refer to drive unit and coupling manufacturers for their long-term storage procedures.

You can purchase long-term storage treatment with the initial unit order or you can purchase it and apply it after the units are already in the field. Contact your local ITT sales representative.

# 3 Product Description

## 3.1 General description

### Model 3298

Model 3298 is a sealless, close-coupled or frame-mounted, centrifugal pump with an enclosed impeller that is driven by a synchronous magnetic coupling. All sizes of the 3298 meet the dimensional standards of ANSI B73.1 except for 1x1.5-5 and the 1.5x2-6.

### Model SP3298

SP3298 is a self-priming, sealless, close-coupled or frame-mounted, centrifugal pump with an enclosed impeller that is driven by a synchronous magnetic coupling. The pump and the frame or adapter feet locations meet ANSI B73.1 dimensional standards.

### Model V 3298

V3298 is a vertical in-line, sealless, close-coupled centrifugal pump with an enclosed impeller that is driven by a synchronous magnetic coupling. Model V3298 meets the dimensional standards of ANSI B73.2.

### Casing

The casings are one-piece cast ductile iron lined with 1/8-inch Tefzel® and have ANSI class 150 flanges with a Tefzel® raised face. The 3298 and SP3298 are end-suction, top centerline discharge, and are self-venting. The V3298 is side-suction, side-discharge, and is also self-venting.

### Impeller magnet assembly

The 3298 family uses a one- or two-piece impeller magnet assembly. The magnet ring is balanced to ISO 1940 G6.3 levels and is sealed within the solid, enclosed Tefzel® impeller magnet assembly.

### Stationary shaft

The impeller magnet assembly rotates about a solid stationary silicon carbide shaft. The shaft is supported at one end by the containment shell and at the other end by the Tefzel® bearing spider.

### Bearing spider

The bearing spider, constructed from solid Tefzel®, houses one of the key silicon carbide thrust bearings in the pump and supports the stationary shaft at one end.

### Rear impeller wear ring

A rear impeller wear ring is standard on M and L group pumps. A wear ring is not required on the S group. The wear ring is pressed into the rear of the impeller assembly. The wear ring reduces axial thrust in the M and L group pumps.

### Magnetic coupling

The magnetic coupling is a coaxial synchronous type using rare earth magnets of neodymium iron (NdFe). This concept results in a compact design and allows the impeller to turn at the same speed as the motor, which means that there is no slip between the drive and the driven magnets.

### Containment shell

The containment shell isolates the pumped liquid from the atmosphere. The containment shell construction is backed with vinylester FRP.

## Bearings

The standard material for radial bearings and thrust bearings is carbon. Pure Sintered Alpha Grade Silicon Carbide or DryGuard® Pure Sintered Alpha Grade Silicon Carbide are optional.

## Standard close-coupled mounting

The drive magnet assembly is keyed, setscrewed, and mounted directly to the motor shaft. This arrangement eliminates the need to perform pump-to-motor alignment.

## Optional frame-mounted power end

The standard configuration for the optional power end is cast iron with flood-oil-lubricated ball bearings. Pure oil mist systems are available as an option. For the protection and reliability of the bearings and the lubricant, a labyrinth seal is provided. On the inboard side a lip seal is used to prevent leakage of oil into the magnetic drive assembly. The frame-mounted power end is not available on the V3298.

# 3.2 Nameplate information

## Important information for ordering

Every pump has nameplates that provide information about the pump. The nameplates are located on the casing and the bearing frame.

When you order spare parts, identify this pump information:

- Model
- Size
- Serial number
- Item numbers of the required parts


Item numbers can be found in the spare parts list.

Refer to the nameplate on the pump casing for most of the information. See Parts List for item numbers.

## Nameplate types

Nameplate	Description
Pump casing	Provides information about the hydraulic characteristics of the pump.
Pump	The formula for the pump size is: Discharge x Suction - Nominal Maximum Impeller Diameter in inches. (Example: 2x3-8)
Bearing frame	Provides information about the lubrication system used.
Ex	If applicable, your pump unit might have an Ex nameplate affixed to the pump, the baseplate, or the discharge head. The nameplate provides information about the Ex specifications of this pump.

**Nameplate on the pump casing using English units**




**Figure 7: Nameplate on the pump casing using English units**

**Table 3: Explanation of nameplate on the pump casing**

Nameplate field	Explanation
IMPLR. DIA.	Impeller diameter, in inches
MAX. DIA.	Maximum impeller diameter, in inches
GPM	Rated pump flow, in gallons per minute
FT HD	Rated pump head, in feet
RPM	Rated pump speed, revolutions per minute
MOD.	Pump model
SIZE	Size of the pump
STD. NO.	ANSI standard designation
MAT L. CONST.	Material of which the pump is constructed
SER. NO.	Serial number of the pump
MAX DSGN PSI @ 100°F	Maximum pressure at 100°F according to the pump design

**Nameplate on the pump casing using metric units**



**Figure 8: Metric units - nameplate on pump casing**

**Table 4: Explanation of the nameplate on the pump casing**

Nameplate field	Explanation
IMPLR. DIA.	Impeller diameter
MAX. DIA.	Maximum impeller diameter
M <sup>3</sup> /HR	Rated pump flow, in cubic meters per hour
M HD	Rated pump head, in meters
RPM	Rated pump speed, in revolutions per minute
MOD.	Pump model
SIZE	Size of the pump

Nameplate field	Explanation
STD. NO.	ANSI standard designation
MAT L. CONST	Material of which the pump is constructed
SER. NO.	Serial number of the pump
MAX. DSGN KG/CM <sup>3</sup> @ 20°C	Kilograms per cubic centimeter at 20°C

### Nameplate on the bearing frame




Figure 9: Nameplate on the bearing frame

Table 5: Explanation of the nameplate on the bearing frame

Nameplate field	Explanation
BRG. O. B.	Outboard bearing designation
BRG. I. B.	Inboard bearing designation
S/N	Serial number of the pump
LUBE	Lubricant, oil or grease

### Ex nameplate

All pumping unit (pump, seal, coupling, motor and pump accessories) certified for use in an Ex classified environment, are identified by an Ex tag secured to the pump or baseplate on which it is mounted. A typical tag would look like this:




Figure 10: Typical Ex nameplate



Figure 11: Typical UKCA Ex nameplate

Table 6: Temperature class definitions

Code	Maximum permissible surface temperature in °C   °F	Maximum permissible liquid temperature in °C   °F
T1	440   824	372   700
T2	290   554	267   513
T3	195   383	172   342
T4	130   266	107   225
T5	Option not available	Option not available

### 3.2 Nameplate information

---

Code	Maximum permissible surface temperature in °C   °F	Maximum permissible liquid temperature in °C   °F
T6	Option not available	Option not available

The code classification marked on the equipment should be in accordance with the specified area where the equipment will be installed. If it is not, please contact your ITT/Goulds representative before proceeding.



---

**WARNING:**

Use of equipment unsuitable for the environment can pose risks of ignition and/or explosion. Ensure the pump driver and all other auxiliary components meet the required area classification at the site. If they are not compatible, do not operate the equipment and contact an ITT representative before proceeding.

---



# 4 Installation

## 4.1 Pre-installation

### Precautions



#### WARNING:

- When installing in a potentially explosive environment, ensure that the motor is properly certified.
- All equipment being installed must be properly grounded to prevent unexpected discharge. Discharge can cause equipment damage, electric shock, and result in serious injury. Test the ground lead to verify it is connected correctly.

#### NOTICE:

- Electrical connections must be made by certified electricians in compliance with all international, national, state and local regulations.
- Supervision by an authorized ITT representative is recommended to ensure proper installation. Improper installation may result in equipment damage or decreased performance.

Evaluate the installation in order to determine that the Net Positive Suction Head Available (NPSH<sub>A</sub>) meets or exceeds the Net Positive Suction Head Required (NPSH<sub>R</sub>), as stated by the pump performance curve.

### 4.1.1 Pump location guidelines

Guideline	Explanation/comment
Keep the pump as close to the liquid source as practically possible.	This minimizes the friction loss and keeps the suction piping as short as possible.
Make sure that the space around the pump is sufficient.	This facilitates ventilation, inspection, maintenance, and service.
If you require lifting equipment such as a hoist or tackle, make sure that there is enough space above the pump.	This makes it easier to properly use the lifting equipment and safely remove and relocate the components to a safe location.
Protect the unit from weather and water damage due to rain, flooding, and freezing temperatures.	This is applicable if nothing else is specified.
Do not install and operate the equipment in closed systems unless the system is constructed with properly-sized safety devices and control devices.	Acceptable devices: <ul style="list-style-type: none"> <li>• Pressure relief valves</li> <li>• Compression tanks</li> <li>• Pressure controls</li> <li>• Temperature controls</li> <li>• Flow controls</li> </ul> If the system does not include these devices, consult the engineer or architect in charge before you operate the pump.
Take into consideration the occurrence of unwanted noise and vibration.	The best pump location for noise and vibration absorption is on a concrete floor with subsoil underneath.
If the pump location is overhead, undertake special precautions to reduce possible noise transmission.	Consider a consultation with a noise specialist.

## 4.1.2 Foundation requirements

### Precautions




#### WARNING:

Risk of serious injury or death in Ex-classified environments. If the pump is a Model NM3171, NM3196, 3198, CV3198, 3298, V3298, SP3298, 4150, 4550, or 3107, ignition due to static electric discharge is possible from plastic parts that are not properly grounded. If the pumped fluid is non-conductive, drain and flush the pump with a conductive fluid under conditions that will not allow for a spark to be released to the atmosphere.

### Requirements


- The location and size of the foundation bolt holes must match those shown on the assembly drawing provided with the pump data package.
- The foundation must weigh between two and three times the weight of the pump.
- Provide a flat, substantial concrete foundation in order to prevent strain and distortion when you tighten the foundation bolts.
- Sleeve-type and J-type foundation bolts are most commonly used. Both designs allow movement for the final bolt adjustment.

### Sleeve-type bolts



Item	Description
1.	Baseplate
2.	Shims
3.	Foundation
4.	Sleeve
5.	Dam
6.	Bolt

Figure 12: Sleeve type bolts

**J-type bolts**

Item	Description
1.	Baseplate
2.	Shims or wedges
3.	Foundation
4.	Dam
5.	Bolt

**Figure 13: J-type bolts**

## 4.2 Baseplate-mounting procedures

### 4.2.1 Prepare the baseplate for mounting

1. Remove all the attached equipment from the baseplate.
2. Clean the underside of the baseplate completely.
3. If applicable, coat the underside of the baseplate with an epoxy primer.  
Use an epoxy primer only if using an epoxy-based grout.
4. Remove the rust-proofing coat from the machined mounting pads using an appropriate solvent.
5. Remove water and debris from the foundation-bolt holes.


### 4.2.2 Install the baseplate using shims or wedges

Required tools:

- Two sets of shims or wedges for each foundation bolt
- Two machinist's levels
- Baseplate-leveling worksheet


This procedure is applicable to cast iron and fabricated steel baseplates.

1. Remove water and debris from the anchor bolt holes and sleeves.
2. If you use sleeve-type bolts, fill the bolt sleeves with packing material or rags to prevent grout from entering the bolt holes.
3. Put the sets of wedges or shims on each side of each foundation bolt.  
Make sure that the wedges extend 19 mm | 0.75 in. to 38 mm | 1.5 in. above the foundation to provide adequate space for grouting. The wedges will provide adequate support for the baseplate after it is grouted.



1. Shims or wedges

**Figure 14: Top view**



1. Shims or wedges

**Figure 15: Side view**

4. Lower the baseplate carefully onto the foundation bolts.
5. Put the machinist's levels across the mounting pads of the driver and the mounting pads of the pump.

---

**NOTICE:**

Remove all dirt from the mounting pads in order to ensure that the correct leveling is achieved. Failure to do so can result in equipment damage or decreased performance.

6. Level the baseplate both lengthwise and across by adding or removing shims or moving the wedges.

These are the leveling tolerances:

- A maximum difference of 3.2 mm | 0.125 in. lengthwise
- A maximum difference of 1.5 mm | 0.059 in. across

You can use the baseplate-leveling worksheet when you take the readings.

7. Hand-tighten the nuts for the foundation.

### 4.2.3 Install the baseplate using jackscrews


Tools required:

- Anti-seize compound
- Jackscrews
- Bar stock
- Two machinist's levels
- Baseplate-leveling worksheet

This procedure applies to the feature-fabricated steel baseplate and the advantage base baseplate.

1. Apply an anti-seize compound on the jackscrews.  
The compound makes it easier to remove the screws after you grout.
2. Lower the baseplate carefully onto the foundation bolts and perform these steps:

- a) Cut the plates from the bar stock and chamfer the edges of the plates in order to reduce stress concentrations.
- b) Put the plates between the jackscrews and the foundation surface.
- c) Use the four jackscrews in the corners in order to raise the baseplate above the foundation. Make sure that the distance between the baseplate and the foundation surface is between 19 mm | 0.75 in. and 38 mm | 1.50 in.
- d) Make sure that the center jackscrews do not touch the foundation surface yet.



Item	Description
1.	Jackscrew
2.	Baseplate
3.	Foundation
4.	Plate

**Figure 16: Jackscrews**

3. Level the driver mounting pads:

---


**NOTICE:**

Remove all dirt from the mounting pads in order to ensure that the correct leveling is achieved. Failure to do so can result in equipment damage or decreased performance.

---

- a) Put one machinist's level lengthwise on one of the two pads.
- b) Put the other machinist's level across the ends of the two pads.
- c) Level the pads by adjusting the four jackscrews in the corners. Make sure that the machinist's level readings are as close to zero as possible, both lengthwise and across.

Use the baseplate-leveling worksheet when you take the readings.



Item	Description
1.	Machinist's levels
2.	Driver's mounting pads
3.	Foundation bolts
4.	Jackscrews
5.	Grout hole
6.	Pump's mounting pads


**Figure 17: Level driver mounting pads**

4. Turn the center jackscrews down so that they rest on their plates on the foundation surface.
5. Level the pump mounting pads:

**NOTICE:**

Remove all dirt from the mounting pads in order to ensure that the correct leveling is achieved. Failure to do so can result in equipment damage or decreased performance.

- a) Put one machinist's level lengthwise on one of the two pads.
  - b) Put the other level across the center of the two pads.
  - c) Level the pads by adjusting the four jackscrews in the corners.
- Make sure that the machinist's level readings are as close to zero as possible, both lengthwise and across.



Item	Description
1.	Driver's mounting pads
2.	Machinist's levels
3.	Foundation bolts
4.	Jackscrews
5.	Grout hole
6.	Pump's mounting pads

**Figure 18: Level pump mounting pads**

6. Hand-tighten the nuts for the foundation bolts.


7. Check that the driver's mounting pads are level and adjust the jackscrews and the foundation bolts if necessary.

The correct level measurement is a maximum of 0.167 mm/m | 0.002 in./ft .

The maximum variation from one side of the baseplate to the other is 0.38 mm | 0.015 in.

### 4.2.4 Baseplate-leveling worksheet

#### Level measurements



- 1) \_\_\_\_\_
- 2) \_\_\_\_\_
- 3) \_\_\_\_\_
- 4) \_\_\_\_\_
- 5) \_\_\_\_\_
- 6) \_\_\_\_\_
- 7) \_\_\_\_\_
- 8) \_\_\_\_\_
- 9) \_\_\_\_\_
- 10) \_\_\_\_\_
- 11) \_\_\_\_\_
- 12) \_\_\_\_\_
- 13) \_\_\_\_\_
- 14) \_\_\_\_\_
- 15) \_\_\_\_\_
- 16) \_\_\_\_\_
- 17) \_\_\_\_\_
- 18) \_\_\_\_\_



## 4.3 Pump-to-driver alignment

### Precautions



#### WARNING:

- Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.
  - Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
  - Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.

### Alignment methods

Three common alignment methods are used:

- Dial indicator
- Reverse dial indicator
- Laser

Follow the instructions from the equipment manufacturer when you use the reverse dial indicator or laser methods. Detailed instructions for using the dial indicator method are contained in this chapter.

### 4.3.1 Alignment checks

#### When to perform alignment checks

You must perform alignment checks under these circumstances:

- The process temperature changes.
- The piping changes.
- The pump has been serviced.

#### Types of alignment checks

Type of check	When it is used
Initial alignment (cold alignment) check	Prior to operation when the pump and the driver are at ambient temperature.
Final alignment (hot alignment) check	After operation when the pump and the driver are at operating temperature.

#### Initial alignment (cold alignment) checks

When	Why
Before you grout the baseplate	This ensures that alignment can be accomplished.
After you grout the baseplate	This ensures that no changes have occurred during the grouting process.
After you connect the piping	This ensures that pipe strains have not altered the alignment.  If changes have occurred, you must alter the piping to remove pipe strains on the pump flanges.

**Final alignment (hot alignment) checks**

When	Why
After the first run	This ensures correct alignment when both the pump and the driver are at operating temperature.
Periodically	This follows the plant operating procedures.

**4.3.2 Permitted indicator values for alignment checks****NOTICE:**

The specified permitted reading values are valid only at operating temperature. For cold settings, other values are permitted. The correct tolerances must be used. Failure to do so can result in misalignment. Contact ITT for further information.

When dial indicators are used to check the final alignment, the pump and drive unit are correctly aligned when these conditions are true:

- The Total Indicated Reading (T.I.R.) is at 0.05 mm | 0.002 in. or less at operating temperature.
- The tolerance of the indicator is 0.0127 mm per mm | 0.0005 in. per in. of indicator separation for the reverse dial indicator or laser method when the pump and driver are at operating temperature.


**4.3.3 Alignment measurement guidelines**

Guideline	Explanation
Rotate the pump coupling half and the driver coupling half together so that the indicator rods have contact with the same points on the driver coupling half.	This prevents incorrect measurement.
Move or shim only the driver in order to make adjustments.	This prevents strain on the piping installations.
Make sure that the hold-down bolts for the driver are tight when you take indicator measurements.	This keeps the driver stationary since movement causes incorrect measurement.
Make sure that the hold-down bolts for the driver are loose before you make alignment corrections.	This makes it possible to move the driver when you make alignment corrections.
Check the alignment again after any mechanical adjustments.	This corrects any misalignments that an adjustment may have caused.

**4.3.4 Attach the dial indicators for alignment**

You must have two dial indicators in order to complete this procedure.

1. Attach two dial indicators on the pump coupling half (X):
  - a) Attach one indicator (P) so that the indicator rod comes into contact with the perimeter of the driver coupling half (Y).  
This indicator is used to measure parallel misalignment.
  - b) Attach the other indicator (A) so that the indicator rod comes into contact with the inner end of the driver coupling half.  
This indicator is used to measure angular misalignment.



**Figure 19: Dial indicator attachment**


2. Rotate the pump coupling half (X) in order to check that the indicators are in contact with the driver coupling half (Y) but do not bottom out.
3. Adjust the indicators if necessary.

### 4.3.5 Pump-to-driver alignment instructions

#### 4.3.5.1 Perform angular alignment for a vertical correction

1. Set the angular alignment indicator to zero at the top-center position (12 o'clock) of the driver coupling half (Y).
2. Rotate the indicator to the bottom-center position (6 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The coupling halves are farther apart at the bottom than at the top. Perform one of these steps: <ul style="list-style-type: none"> <li>• Add shims in order to raise the feet of the driver at the shaft end.</li> <li>• Remove shims in order to lower the feet of the driver at the other end.</li> </ul>
Positive	The coupling halves are closer at the bottom than at the top. Perform one of these steps: <ul style="list-style-type: none"> <li>• Remove shims in order to lower the feet of the driver at the shaft end.</li> <li>• Add shims in order to raise the feet of the driver at the other end.</li> </ul>



**Figure 20: Side view of an incorrect vertical alignment**

4. Repeat the previous steps until the permitted reading value is achieved.


Maximum permitted value for angular alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

### 4.3.5.2 Perform angular alignment for a horizontal correction

1. Set the angular alignment indicator (A) to zero on left side of the driver coupling half (Y), 90° from the top-center position (9 o'clock).
2. Rotate the indicator through the top-center position to the right side, 180° from the start position (3 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The coupling halves are farther apart on the right side than the left. Perform one of these steps: <ul style="list-style-type: none"> <li>• Slide the shaft end of the driver to the left.</li> <li>• Slide the opposite end to the right.</li> </ul>
Positive	The coupling halves are closer together on the right side than the left. Perform one of these steps: <ul style="list-style-type: none"> <li>• Slide the shaft end of the driver to the right.</li> <li>• Slide the opposite end to the left.</li> </ul>



**Figure 21: Top view of an incorrect horizontal alignment**

4. Repeat the previous steps until the permitted reading value is achieved.

Maximum permitted value for angular alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

### 4.3.5.3 Perform parallel alignment for a vertical correction

Refer to the alignment table in "Permitted indicator values for alignment checks" (see Table of Contents for location of table) for the proper cold alignment value based on the motor temperature rise and the pump operating temperature.

Before you start this procedure, make sure that the dial indicators are correctly set up.


A unit is in parallel alignment when the parallel indicator (P) does not vary by more than 0.05 mm | 0.002 in. as measured at four points 90° apart at the operating temperature.

When aligning a cold unit, see the Cold settings for vertical parallel alignment table.

1. Set the parallel alignment indicator (P) to zero at the top-center position (12 o'clock) of the driver coupling half (Y).
2. Rotate the indicator to the bottom-center position (6 o'clock).
3. Record the indicator reading.

When the reading value is...	Then...
Negative	The pump coupling half (X) is lower than the driver coupling half (Y). Remove shims of a thickness equal to half of the indicator reading value under each driver foot.

When the reading value is...	Then...
Positive	The pump coupling half (X) is higher than the driver coupling half (Y). Add shims of a thickness equal to half of the indicator reading value to each driver foot.



**Figure 22: Side view of an incorrect vertical alignment**

- Repeat the previous steps until the permitted reading value is achieved.

### NOTICE:

The specified permitted reading values are valid only at operating temperature. For cold settings, other values are permitted. The correct tolerances must be used. Failure to do so can result in misalignment. Contact ITT for further information.

Maximum permitted value for parallel alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

During installation, when the pump is cold, adjust the parallel vertical alignment to a setting that allows for expansion rates of the pump and drive at operating temperature:

**Table 7: Cold settings for parallel vertical alignment**

If the operating temperature of the pumped liquid is...	Then, set the driver shaft parallel vertical alignment...
10°C   50°F	0.05 mm   0.002 in. lower
65°C   150°F	0.03 mm   0.001 in. higher
120°C   250°F	0.12 mm   0.005 in. higher

### 4.3.5.4 Perform parallel alignment for a horizontal correction

Refer to the alignment table in "Permitted indicator values for alignment checks" (see Table of Contents for location of table) for the proper cold alignment value based on the motor temperature rise and the pump operating temperature.

A unit is in parallel alignment when the parallel indicator (P) does not vary by more than 0.05 mm | 0.002 in. as measured at four points 90° apart at the operating temperature.

- Set the parallel alignment indicator (P) to zero on the left side of the driver coupling half (Y), 90° from the top-center position (9 o'clock).
- Rotate the indicator through the top-center position to the right side, 180° from the start position (3 o'clock).
- Record the indicator reading.

When the reading value is...	Then...
Negative	The driver coupling half (Y) is to the left of the pump coupling half (X).
Positive	The driver coupling half (Y) is to the right of the pump coupling half (X).


- Slide the driver carefully in the appropriate direction.

---

**NOTICE:**

Make sure to slide the driver evenly. Failure to do so can negatively affect horizontal angular correction.

---



**Figure 23: Top view of an incorrect horizontal alignment**

- Repeat the previous steps until the permitted reading value is achieved.

Maximum permitted value for parallel alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

#### 4.3.5.5 Perform complete alignment for a vertical correction

A unit is in complete alignment when both the angular indicator (A) and the parallel indicator (P) do not vary by more than 0.05 mm | 0.002 in. as measured at four points 90° apart.

- Set the angular and parallel dial indicators to zero at the top-center position (12 o'clock) of the driver coupling half (Y).
- Rotate the indicators to the bottom-center position (6 o'clock).
- Record the indicator readings.
- Make corrections according to the separate instructions for angular and parallel alignment until you obtain the permitted reading values.

Maximum permitted value for angular alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

Maximum permitted value for parallel alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

When the procedure is complete, both the angular and parallel alignment must meet the permitted tolerances.

#### 4.3.5.6 Perform complete alignment for a horizontal correction

A unit is in complete alignment when both the angular indicator (A) and the parallel indicator (P) do not vary by more than 0.05 mm | 0.002 in. as measured at four points 90° apart.

- Set the angular and parallel dial indicators to zero at the left side of the driver coupling half (Y), 90° from the top-center position (9 o'clock).
- Rotate the indicators through the top-center position to the right side, 180° from the start position (3 o'clock).
- Record the indicator readings.
- Make corrections according to the separate instructions for angular and parallel alignment until you obtain the permitted reading values.

Maximum permitted value for angular alignment:

- 0.05 mm | 0.002 in. total indicated runout at operating temperature

Maximum permitted value for parallel alignment:


- 0.05 mm | 0.002 in. total indicated runout at operating temperature

When the procedure is complete, both the angular and parallel alignment must meet the permitted tolerances.

## 4.4 Grout the baseplate

Required equipment:


- Cleaners: Do not use an oil-based cleaner because the grout will not bond to it. See the instructions provided by the grout manufacturer.
  - Grout: Non-shrink grout is recommended.
1. Clean all the areas of the baseplate that will come into contact with the grout.
  2. Build a dam around the foundation.
  3. Thoroughly wet the foundation that will come into contact with the grout.
  4. Pour grout through the grout hole into the baseplate up to the level of the dam.  
When you pour the grout, remove air bubbles from it by using one of these methods:
    - Puddle with a vibrator.
    - Pump the grout into place.
  5. Allow the grout to set.



Item	Description
1.	Baseplate
2.	Shims or wedges
3.	Grout
4.	Foundation
5.	Sleeve
6.	Dam
7.	Bolt

**Figure 24: Pour grout into baseplate**

6. Fill the remainder of the baseplate with grout, and allow the grout to set for at least 48 hours.



Item	Description
1.	Baseplate
2.	Grout
3.	Foundation
4.	Dam
5.	Bolt

**Figure 25: Fill remainder of baseplate with grout**

7. Tighten the foundation bolts.
8. Recheck the alignment.

## 4.5 Piping checklists

### 4.5.1 Fastening



**WARNING:**

Risk of serious personal injury or property damage. Fasteners such as bolts and nuts are critical to the safe and reliable operation of the product. Ensure appropriate use of fasteners during installation or reassembly of the unit.

- Use fasteners of the proper size and material only.
  - Replace all corroded fasteners.
  - Ensure that all fasteners are properly tightened and that there are no missing fasteners.
- 

### 4.5.2 General piping checklist

**Precautions**



**WARNING:**

- Risk of serious personal injury or property damage. Fasteners such as bolts and nuts are critical to the safe and reliable operation of the product. Ensure appropriate use of fasteners during installation or reassembly of the unit.
    - Use fasteners of the proper size and material only.
    - Replace all corroded fasteners.
    - Ensure that all fasteners are properly tightened and that there are no missing fasteners.
-



**CAUTION:**

Do not move the pump to the pipe. This could make final alignment impossible.

**CAUTION:**

Never draw piping into place at the flanged connections of the pump. This can impose dangerous strains on the unit and cause misalignment between the pump and driver. Pipe strain adversely affects the operation of the pump, which results in physical injury and damage to the equipment.

Flange loads from the piping system, including those from the thermal expansion of the piping, must not exceed the limits of the pump. Deformation can result in contact with rotating parts, which can result in excess heat generation, sparks, and premature failure.

**NOTICE:**

Vary the capacity with the regulating valve in the discharge line. Never throttle the flow from the suction side. This action can result in decreased performance, unexpected heat generation, and equipment damage.

**Piping guidelines**

Guidelines for piping are given in the Hydraulic Institute Standards available from the Hydraulic Institute at 9 Sylvan Way, Parsippany, NJ 07054-3802. You must review this document before you install the pump.

**Checklist**


Check	Explanation/comment	Checked
Check that all piping is supported independently of, and lined up naturally with, the pump flange. See Alignment criteria for pump flanges.	<ul style="list-style-type: none"> <li>Strain on the pump</li> <li>Misalignment between the pump and the drive unit</li> <li>Wear on the pump bearings and the coupling</li> </ul> If an isolation base is used, then use flexible piping on the discharge and suction connections.	
Keep the piping as short as possible.	This helps to minimize friction losses.	
Keep the piping as straight as possible. Avoid unnecessary bends. Use 45° or long radius 90° fittings where necessary.	This helps to minimize friction losses.	
Check that only necessary fittings are used.	This helps to minimize friction losses.	
Make sure that the inside diameters match properly when you use flange joints.	—	
Do not connect the piping to the pump until: <ul style="list-style-type: none"> <li>The grout for the baseplate or sub-base becomes hard.</li> <li>The grout for the pit cover becomes hard.</li> <li>The hold-down bolts for the pump and the driver are tightened.</li> </ul>	—	

#### 4.5 Piping checklists

Check	Explanation/comment	Checked
Make sure that all the piping joints and fittings are airtight.	If the pump housing has threaded connections, then use a PTFE tape sealer or a high-quality thread sealant.	
If the pump handles corrosive fluids, make sure that the piping allows you to flush out the liquid before you remove the pump.		
	This helps to prevent misalignment due to linear expansion of the piping. This helps to prevent misalignment due to thermal expansion of the piping.	
Make sure that all piping components, valves and fittings, and pump branches are clean prior to assembly.	—	
Make sure that the isolation and check valves are installed in the discharge line.	Locate the check valve between the isolation valve and the pump. This will permit inspection of the check valve. The isolation valve is required for regulation of flow, and for inspection and maintenance of the pump. The check valve prevents pump or seal damage due to reverse flow through the pump when the driver is turned off.	
Use cushioning devices.	This protects the pump from surges and water hammer if quick-closing valves are installed in the system.	
In no case should loads on the pump flanges exceed the limits stated in API Standard 610, 11th Edition (ISO 13709).	Bottom of casing should be supported by a solid foundation or casing feet should be used.	

#### Alignment criteria for pump flanges

Type	Criteria
Axial	The flange gasket thickness $\pm 0.8$ mm   0.03 in.
Parallel	Align the flange to be within 0.025 mm/mm to 0.8 mm/mm   0.001 in./in. to 0.03 in./in. of the flange diameter.
Concentric	You can easily install the flange bolts by hand.

**Example: Installation for expansion****4.5.3 Suction-piping checklist****Performance curve reference****CAUTION:**

Vary the capacity with the regulating valve in the discharge line. Never throttle the flow from the suction side. This action can result in decreased performance, unexpected heat generation, and equipment damage.

Net positive suction head available (NPSH<sub>A</sub>) must always exceed NPSH required (NPSH<sub>R</sub>) as shown on the published performance curve of the pump.

If a suction lift over 3 m | 10 ft. and a liquid temperature higher than 49°C | 120°F are required, then read the pump performance curve for the NPSH<sub>R</sub>.

**Suction-piping checks**

Check	Explanation/comment	Checked
Flush all suction piping before you connect it to the pump.	This reduces the risk of pump operation problems.	
Check that the distance between the inlet flange of the pump and the closest elbow is at least two pipe diameters.	This minimizes the risk of cavitation in the suction inlet of the pump due to turbulence. See the Example sections for illustrations.	
Check that elbows in general do not have sharp bends.	See the Example sections for illustrations. —	

#### 4.5 Piping checklists

Check	Explanation/comment	Checked
<p>Check that the suction piping is one or two sizes larger than the suction inlet of the pump.</p> <p>Install an eccentric reducer between the pump inlet and the suction piping.</p>	<p>The suction piping must never have a smaller diameter than the suction inlet of the pump.</p> <p>See the Example sections for illustrations.</p>	
<p>Check that the eccentric reducer at the suction flange of the pump has the following properties:</p> <ul style="list-style-type: none"> <li>• Sloping side down</li> <li>• Horizontal side at the top</li> </ul>	<p>See the example illustrations.</p>	
<p>Suggested suction strainers are used.</p> <p>Check that they are at least three times the area of the suction piping.</p> <p>Monitor the pressure drop across the suction strainer.</p> <p>An increased pressure drop across the strainer of 34.5 kPa   5 psi indicates that the strainer should be removed and cleaned.</p> <p>After a period of time (24 hours minimum) system flushing should be complete and the suction strainer can be removed.</p>	<p>Suction strainers help to prevent debris from entering the pump.</p> <p>Mesh holes with a minimum diameter of 1.6 mm   1/16 in. are recommended.</p> <p>Liquids with specific gravity less than 0.60 a pressure drop across the suction strainer may be due to ice buildup. Ice buildup can cause turbulence, low pressure areas and pumpage vaporization.</p>	
<p>If more than one pump operates from the same liquid source, check that separate suction-piping lines are used for each pump.</p>	<p>This recommendation helps you to achieve a higher pump performance and prevent vapor locking especially with specific gravity of liquid less than 0.60.</p>	
<p>If necessary, make sure that the suction piping includes a drain valve and that it is correctly installed.</p>	—	
<p>Assure adequate insulation is applied for liquids with specific gravity less than 0.60.</p>	<p>To assure sufficient NPSHa.</p>	



#### Liquid source below the pump

Check	Explanation/comment	Checked
<p>Make sure that the suction piping is free from air pockets.</p>	<p>This helps to prevent the occurrence of air and cavitation in the pump inlet.</p>	
<p>Check that the suction piping slopes upwards from the liquid source to the pump inlet.</p>	—	
<p>Check that all joints are air-tight.</p>	—	
<p>If the pump is not self-priming, check that a device for priming the pump is installed.</p>	<p>Use a foot valve with a diameter that is at least equivalent to the diameter of the suction piping.</p>	



### Liquid source above the pump

Check	Explanation/comment	Checked
Check that an isolation valve is installed in the suction piping at a distance of at least two times the pipe diameter from the suction inlet.	This permits you to close the line during pump inspection and maintenance. Do not use the isolation valve to throttle the pump. Throttling can cause these problems: <ul style="list-style-type: none"> <li>• Loss of priming</li> <li>• Excessive temperatures</li> <li>• Damage to the pump</li> <li>• Voiding the warranty</li> </ul>	
Make sure that the suction piping is free from air pockets.	This helps to prevent the occurrence of air and cavitation in the pump inlet.	
Check that the piping is level or slopes downward from the liquid source.	—	
Make sure that no part of the suction piping extends below the suction flange of the pump.	—	
Make sure that the size of the entrance from the supply is one or two sizes larger than the suction pipe.	—	
Make sure that the suction piping is adequately submerged below the surface of the liquid source.	This prevents air from entering the pump through a suction vortex.	

### Example: Elbow close to the pump suction inlet

Correct	Incorrect
<p>The correct distance between the inlet flange of the pump and the closest elbow is at least two pipe diameters.</p>  <ol style="list-style-type: none"> <li>1. Enough distance to prevent cavitation</li> <li>2. Eccentric reducer with a level top</li> </ol>	

**Example: Suction piping equipment**

Correct	Incorrect
 <ol style="list-style-type: none"> <li>1. Suction pipe sloping upwards from liquid source</li> <li>2. Long-radius elbow</li> <li>3. Strainer</li> <li>4. Foot valve</li> <li>5. Eccentric reducer with a level top</li> </ol>	 <ol style="list-style-type: none"> <li>1. Air pocket, because the eccentric reducer is not used and because the suction piping does not slope gradually upward from the liquid source</li> </ol>



**4.5.4 Discharge piping checklist**

**Checklist**

Check	Explanation/comment	Checked
<p>Check that an isolation valve is installed in the discharge line. For specific gravity less than 0.60, minimize distance from pump discharge.</p>	<p>The isolation valve is required for:</p> <ul style="list-style-type: none"> <li>• Priming</li> <li>• Regulation of flow</li> <li>• Inspection and maintenance of the pump</li> <li>• Reduce risk of pumpage vaporization and vapor locking at low flow rates for low specific gravity liquids.</li> </ul> <p>See Example: Discharge piping equipment for illustrations.</p>	
<p>Check that a check valve is installed in the discharge line, between the isolation valve and the pump discharge outlet.</p>	<p>The location between the isolation valve and the pump allows inspection of the check valve.</p> <p>The check valve prevents damage to the pump and seal due to the back flow through the pump, when the drive unit is shut off. It is also used to restrain the liquid flow.</p> <p>See Example: Discharge piping equipment for illustrations.</p>	
<p>If increasers are used, check that they are installed between the pump and the check valve.</p>	<p>See Example: Discharge piping equipment for illustrations.</p>	

Check	Explanation/comment	Checked
If quick-closing valves are installed in the system, check that cushioning devices are used.	This protects the pump from surges and water hammer.	

**Example: Discharge piping equipment**

Correct	Incorrect
 <p>1. Bypass line 2. Shut-off valve 3. Check valve 4. Discharge isolation valve</p>	 <p>1. Check valve (incorrect position) 2. The isolation valve should not be positioned between the check valve and the pump.</p>

**4.5.5 Final piping checklist**



**WARNING:**



A build-up of gases within the pump, sealing system, or process piping system may result in an explosive environment. Make sure the process piping system, pump and sealing system are properly vented prior to operation.

Check	Explanation/comment	Checked
Check that the shaft rotates smoothly.	Rotate the shaft by hand. Make sure there is no rubbing that can lead to excess heat generation or sparks.	
Re-check the alignment to make sure that pipe strain has not caused any misalignment.	If pipe strain exists, then correct the piping.	

# 5 Commissioning, Startup, Operation, and Shutdown

## 5.1 Preparation for startup



---

**WARNING:**

- Risk of serious physical injury or death. Exceeding any of the pump operating limits (e.g. - pressure, temperature, power, etc.) could result in equipment failure, such as explosion, seizure, or breach of containment. Assure that the system operating conditions are within the capabilities of the pump.
  - Risk of death or serious injury. Leaking fluid can cause fire and/or burns. Ensure all openings are sealed prior to filling the pump.
  - Breach of containment can cause fire, burns, and other serious injury. Failure to follow these precautions before starting the unit may lead to dangerous operating conditions, equipment failure, and breach of containment.
  - Risk of explosion and serious physical injury. Do not operate pump with blocked system piping or with suction or discharge valves closed. This can result in rapid heating and vaporization of pumpage.
  - Do not operate pump below hydraulic or thermal minimum flow. For hydraulic minimum flows refer to technical manual and pump performance curve. To calculate thermal minimum flow, refer to HI Centrifugal Pumps for Design and Application ANSI/HI 1.3-2000.
  - Risk of breach of containment and equipment damage. Ensure the pump operates only between minimum and maximum rated flows. Operation outside of these limits can cause high vibration, mechanical seal and/or shaft failure, and/or loss of prime.
- 



---

**WARNING:**

- Risk of death, serious personal injury, and property damage. Heat and pressure buildup can cause explosion, rupture, and discharge of pumpage. Never operate the pump with suction and/or discharge valves closed.
- Running a pump without safety devices exposes operators to risk of serious personal injury or death. Never operate a unit unless appropriate safety devices (guards, etc.) are properly installed.
- Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.
  - Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
  - Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.



- When installing in a potentially explosive environment, ensure that the motor is properly certified.



- Risk of seizure, breach of containment, or explosion. Ensure balance line is installed and piped back to either the pump suction or suction vessel. This prevents rapid vaporization of the pumped fluid.

---

### Precautions



---

**WARNING:**

The mechanical seal used in an Ex-classified environment must be properly certified.

---



---

**CAUTION:**

When a cartridge mechanical seal is used, ensure that the set screws in the seal locking ring are tightened and that the centering clips have been removed prior to startup. This prevents seal or shaft sleeve damage by ensuring that the seal is properly installed and centered on the sleeve.

---

---

**NOTICE:**

- Verify the driver settings before you start any pump. Refer to the applicable drive equipment IOMs and operating procedures.
  - Excessive warm-up rates can cause equipment damage. Ensure the warm-up rate does not exceed 1.4°C | 2.5°F per minute.
- 

---

**NOTICE:**

You must follow these precautions before you start the pump:

- Flush and clean the system thoroughly to remove dirt or debris in the pipe system in order to prevent premature failure at initial startup.
  - Bring variable-speed drivers to the rated speed as quickly as possible.
  - Run a new or rebuilt pump at a speed that provides enough flow to flush and cool the close-running surfaces of the stuffing-box bushing.
  - If temperatures of the pumped fluid will exceed 93°C | 200°F, then warm up the pump prior to operation. Circulate a small amount of fluid through the pump until the casing temperature is within 38°C | 100°F of the fluid temperature. Accomplish this by flowing fluid from pump inlet to discharge drain (optionally, the casing vent can be included in warm-up circuit but not required). Soak for (2) hours at process fluid temperature.
- 


At initial startup, do not adjust the variable-speed drivers or check for speed governor or over-speed trip settings while the variable-speed driver is coupled to the pump. If the settings have not been verified, then uncouple the unit and refer to instructions supplied by the driver manufacturer.

## 5.2 Remove the coupling guard


1. Remove the nut, bolt, and washers from the slotted hole in the center of the coupling guard.
2. Slide the driver half of the coupling guard toward the pump.

## 5.2 Remove the coupling guard

---




3. Remove the nut, bolt, and washers from the driver half of the coupling guard.
4. Remove the driver half of the coupling guard:
  - a) Slightly spread the bottom apart.
  - b) Lift upwards.



Item	Description
1.	Annular groove
2.	Driver half of the coupling guard
3.	Driver

5. Remove the remaining nut, bolt, and washers from the pump half of the coupling guard.  
It is not necessary to remove the end plate from the pump side of the bearing housing. You can access the bearing-housing tap bolts without removing this end plate if maintenance of internal pump parts is necessary.
6. Remove the pump half of the coupling guard:
  - a) Slightly spread the bottom apart.
  - b) Lift upwards.



Item	Description
1.	Annular groove
2.	Pump-side end plate
3.	Driver
4.	Pump half of the coupling guard

## 5.3 Check the rotation



### WARNING:

- Starting the pump in reverse rotation can result in the contact of metal parts, heat generation, and breach of containment. Ensure correct driver settings prior to starting any pump.
- Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.
  - Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
  - Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.

### Frame Mounted:

1. Lock out power to the driver.
2. Make sure that the coupling hubs are fastened securely to the shafts.
3. Make sure that the coupling spacer is removed.  
The pump ships with the coupling spacer removed.
4. Unlock power to the driver.
5. Make sure that everyone is clear, and then jog the driver long enough to determine that the direction of rotation corresponds to the arrow on the bearing housing or close-coupled frame.
6. Lock out power to the driver.

## 5.4 Check the rotation - Close Coupled

---



### WARNING:

- Starting the pump in reverse rotation can result in the contact of metal parts, heat generation, and breach of containment. Ensure correct driver settings prior to starting any pump.
  - Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.
    - Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
    - Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.
- 

### Close Coupled:

1. Lock out power to the driver.
2. Make sure that everyone is clear. Jog the driver momentarily, about a half a second. You should be able to check motor rotation by observing the motor fan direction. The direction should be the same as the arrow on the close coupled frame.
3. Lock out power to the driver.

## 5.5 Couple the pump and driver

---



### WARNING:

Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.

- Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
  - Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.
- 



Couplings must have proper certification to be used in an Ex classified environment. Use the instructions from the coupling manufacturer in order to lubricate and install the coupling. Refer to driver/coupling/gear manufacturers IOM for specific instructions and recommendations.

### 5.5.1 Install the coupling guard

---



### WARNING:

- Running a pump without safety devices exposes operators to risk of serious personal injury or death. Never operate a unit unless appropriate safety devices (guards, etc.) are properly installed.
- Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.


- Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
- Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.



**WARNING:**

The coupling guard used in an Ex classified environment must be properly certified and constructed from a spark resistant material.

**Required parts:**




Item	Description	Item	Description
1.	End plate, drive end	4	3/8-16 nut, 3 required
2.	End plate, pump end	5	3/8 in. washer
3.	Guard half, 2 required	6	3/8-16 x 2 in. hex head bolt, 3 required


**Figure 26: Required parts**

1. De-energize the motor, place the motor in a locked-out position, and place a caution tag at the starter that indicates the disconnect.
2. Put the pump-side end plate in place.  
If the pump-side end plate is already in place, make any necessary coupling adjustments and then proceed to the next step.

If the pump size is...	Then...
STX, MTX, LTX	Align the pump-side end plate to the bearing frame. You do not need to adjust the impeller.


**STX, MTX, LTX**





Item	Description
1.	Driver
2.	Pump end plate
3.	Bearing housing
4.	Jam nut


3. Put the pump-half of the coupling guard in place:
  - a) Slightly spread the bottom apart.
  - b) Place the coupling guard half over the pump-side end plate.



Item	Description
1.	Annular groove
2.	Pump-side end plate
3.	Driver
4.	Pump half of the coupling guard

**Figure 27: Guard half installation**


The annular groove in the coupling guard half must fit around the end plate.



Item	Description
1.	Annular groove
2.	End plate (pump end)
2.	Guard half

**Figure 28: Annular groove in coupling guard**


4. Use a bolt, a nut, and two washers to secure the coupling guard half to the end plate. Tighten securely.



Item	Description
1.	Nut
2.	Washer
3.	Bolt


**Figure 29: Secure coupling guard half to end plate**

5. Put the driver half of the coupling guard in place:
  - a) Slightly spread the bottom apart.
  - b) Place the driver half of the coupling guard over the pump half of the coupling guard. The annular groove in the coupling guard half must face the motor.



Item	Description
1.	Annular groove
2.	Driver half of the coupling guard
3.	Driver


- Place the driver-side end plate over the motor shaft.



**Figure 30: Placement of driver half of coupling guard**

- Place the driver-side end plate in the annular groove of the driver-half of the coupling guard.
- Use a bolt, a nut, and two washers to secure the coupling guard half to the end plate. Hand-tighten only.  
The hole is located on the driver-side of the coupling guard half.
- Slide the driver-half of the coupling guard towards the motor so that the coupling guard completely covers the shafts and coupling.





**Figure 31: Slide driver-half of coupling guard towards motor**

10. Use a nut, a bolt, and two washers to secure the coupling guard halves together.
11. Tighten all nuts on the guard assembly.

## 5.6 Bearing lubrication



### WARNING:

Pumps are shipped without oil. Oil-lubricated anti-friction bearings must be lubricated at the job site.



Risk of explosive hazard and premature failure from sparks and heat generation. Ensure bearings are properly lubricated prior to startup.

These bearing lubrication sections list different pumped-fluid temperatures. If your pump is ATEX certified and your pumped-fluid temperature exceeds the permitted temperature values, then consult your ITT representative.

Pump type	Pump model	Requirements
Close coupled	3298 SP3298 V3298	Close coupled pumps do not have bearings which require lubrication.
Frame mounted	3298 SP3298	<ul style="list-style-type: none"> <li>• Oil level is measured through the sight glass.</li> <li>• Oil level must not fall below the center of the sight glass.</li> <li>• An increase in level may be noted after startup due to oil circulation within the bearing frame.</li> </ul>

### 5.6.1 Lubricating oil requirements

Use a high quality turbine oil with rust and oxidation inhibitors.

#### Lubricating oil requirements

	Bearing temperature below 82°C   180°F	Bearing temperature above 82°C   180°F
<b>ISO grade</b>	<b>ISO viscosity grade 68</b>	<b>ISO viscosity grade 100</b>
Approximate SSU at 38°C   100°F	300	470
DIN 51517	C68	C100

	<b>Bearing temperature below 82°C   180°F</b>	<b>Bearing temperature above 82°C   180°F</b>
<b>ISO grade</b>	<b>ISO viscosity grade 68</b>	<b>ISO viscosity grade 100</b>
Kinematic viscosity at 40°C   105°F mm <sup>2</sup> /sec	68	100

### 5.6.2 Acceptable oil for lubricating bearings

**Acceptable lubricants**

**Table 8: Acceptable lubricants**

Brand	Lubricant type
Chevron	GST Oil 68
Exxon	NUTHO H68
Mobil	DTE Heavy Medium
Phillips 66	Turbine Oil VG68
	MM motor oil SAE 20-20W
	HDS motor oil SAE 20-20W
Shell	Turbo T 68
Gulf	Harmony 68

### 5.6.3 Lubricate the bearings with oil




**WARNING:**

Risk of explosive hazard and premature failure from sparks and heat generation. Ensure bearings are properly lubricated prior to startup.

Use a high-quality turbine oil with rust and oxidation inhibitors.

1. Remove the fill plug.
2. Fill the bearing frame with oil through the filler connection, which is located on top of the bearing frame.

Fill the bearing frame with oil until the oil level reaches the middle of the sight glass (319). The correct volume of oil required for each size of bearing frame can be found in the 'Oil Volume Requirements' section in the 'Bearing Maintenance' / 'Maintenance' portion of the IOM.




**Figure 32: Oil filler connection**

3. Replace the fill plug.

## 5.7 Pump priming

### 5.7.1 Prime the pump with the suction supply above the pump

1. Slowly open the suction isolation valve.
2. Open the air vents on the suction and discharge piping until the pumped fluid flows out.
3. Close the air vents.




Item	Description
1.	Discharge isolation valve
2.	Check valve
3.	Suction isolation valve

**Figure 33: Suction supply above pump**

### 5.7.2 Prime the pump with the suction supply below the pump


Use a foot valve and an outside source of liquid in order to prime the pump. The liquid can come from one of these sources:

- A priming pump
  - A pressurized discharge line
  - Another outside supply
1. Close the discharge isolation valve.
  2. Open the air vent valves in the casing.
  3. Open the valve in the outside supply line until only liquid escapes from the vent valves.
  4. Close the vent valves.
  5. Close the outside supply line.



Item	Description
1.	Discharge isolation valve
2.	Shutoff valve
3.	From outside supply
4.	Foot valve
5.	Check valve

**Figure 34: Pump priming with suction supply below pump with foot valve and an outside supply**



Item	Description
1.	By-pass line
2.	Shutoff valve
3.	Foot valve
4.	Check valve
5.	Discharge isolation valve

**Figure 35: Pump priming with suction supply below pump with foot valve using bypass around check valve**

### 5.7.3 Other methods of priming the pump

You can also use these methods in order to prime the pump:

- Prime by ejector
- Prime by automatic priming pump

## 5.8 Start the pump



**WARNING:**

Continuous operation against a closed discharge valve can vaporize liquid. This condition can cause an explosion due to confined vapor that is under high pressure and temperature.



**WARNING:**

Risk of equipment damage, seal failure and breach of containment. Ensure all flush and cooling systems are operating correctly prior to starting pump.

**NOTICE:**

- Risk of equipment damage due to dry operation. Immediately observe the pressure gauges. If discharge pressure is not quickly attained, stop the driver immediately, reprime, and attempt to restart the pump.
- On frame mounted units, ensure that the oil level is correct prior to starting pump. Close coupled pumps do not have oil lubricated bearings.
- Continuous operation against a closed discharge valve will cause the pump to overheat. Overheating the magnetic drive assembly will weaken or ruin the magnets.

**NOTICE:**

Risk of equipment damage on pure or purge-oil mist-lubricated units. Remove the viewing port plugs to verify that oil mist is flowing properly. Reinstall the plugs after confirming.

Before you start the pump, you must perform these tasks:

- Open the suction valve.
  - Open any recirculation or cooling lines.
1. Fully close or partially open the discharge valve, depending on system conditions.
  2. Start the driver.
  3. Slowly open the discharge valve until the pump reaches the desired flow.
  4. Immediately check the pressure gauge to ensure that the pump quickly reaches the correct discharge pressure.
  5. If the pump fails to reach the correct pressure, perform these steps:
    - a) Stop the driver.
    - b) Prime the pump again.
    - c) Restart the driver.
  6. Monitor the pump while it is operating:
    - a) Check the pump for bearing temperature, excessive vibration, and noise.
    - b) If the pump exceeds normal levels, then shut down the pump immediately and correct the problem.  
A pump can exceed normal levels for several reasons. See Troubleshooting for information about possible solutions to this problem.
  7. Repeat steps 5 and 6 until the pump runs properly.

### 5.8.1 Minimum continuous recommended flow

Group	Pump size	60 Hertz			50 Hertz		
		GPM			m3/hr		
		3600	1800	1200	3000	1500	1000
3298							
XS	1 x 1.5 - 5	1	0.5	—	0.2	0.1	—
	1½ x 2 - 6	5	3	—	1	0.5	—
S	1 x 1.5 - 6	5	3	2	2	1	0.5
	1 x 1.5 - 6H	20	10	7	4	2	1
	1 x 1.5 - 8	15	8	4	3	2	1
	1 x 1.5 - 8H	9	5	3	3	2	1
	1 x 1.5 - 8LF	9	5	3	2	1	1
	1½ x 3 - 7	20	10	6	5	2	1

Group	Pump size	60 Hertz			50 Hertz		
		GPM			m3/hr		
		3600	1800	1200	3000	1500	1000
	2 x 3 - 6	30	15	8	6	3	1
M	1½ x 3 - 8	30	15	8	6	3	1
	2 x 3 - 8	50	9	5	9	2	1
	3 x 4 - 7	80	13	9	18	9	6
	3 x 4 - 8	60	30	20	11	6	4
	1 x 2 - 10	30	5	3	5	3	2
	1 x 2 - 10LF	18	9	6	3	2	1
L	1½ x 3 - 10	60	30	20	11	5	4
	1½ x 3-13LF	33	17	13	6	3	2
	2 x 3 - 10	100	50	33	19	10	6
	3 x 4 - 10G	175	90	60	33	16	11
	3 x 4 - 10H	-	90	30	—	17	3
	4 x 6-8	170	85	56	32	16	11
	4 x 6 - 10	-	475 <sup>5</sup>	325 <sup>5</sup>	—	95 <sup>5</sup>	55 <sup>5</sup>
SP3298							
S	1 x 1½ - 6	5	3	2	2	1	0.5
	2 x 3 - 6	30	15	8	6	3	1
V3298							
S	1½ x 2 - 6	5	3	2	2	1	0.5
	1½ 2 - 8	60	30	20	11	7	4
	2 x 3 - 6	60	30	20	11	7	4
M	1½ x 2 - 10	30	5	3	5	0.7	0.5
<ol style="list-style-type: none"> <li>1. All flows are for a continuous operation of 24 hours a day, seven days a week.</li> <li>2. These values are based on water with a specific gravity of 1.0 and specific heat of 1.0.</li> <li>3. You can reliably operate the pumps at lower minimum flows under intermittent operating conditions (less than 15% of the time). Contact ITT for more information.</li> <li>4. Contact the factory for pump efficiency at minimum flows.</li> <li>5. You can operate the pump at substantially lower flows with an adequate NPSH margin. Contact ITT for details.</li> </ol>							

## 5.9 Pump operation precautions

### General considerations



#### WARNING:

- Risk of serious personal injury or property damage. Dry running may cause rotating parts within the pump to seize to non-moving parts. Do not run dry.
- Risk of explosion and serious physical injury. Do not operate pump with blocked system piping or with suction or discharge valves closed. This can result in rapid heating and vaporization of pumpage.

#### NOTICE:

---

### Operation at reduced capacity



---

**WARNING:**

- Risk of breach of containment and equipment damage. Excessive vibration levels can cause damage to bearings, stuffing box, seal chamber, and/or mechanical seal. Observe pump for vibration levels, bearing temperature, and excessive noise. If normal levels are exceeded, shut down and resolve.
  - Risk of explosion and serious physical injury. Do not operate pump with blocked system piping or with suction or discharge valves closed. This can result in rapid heating and vaporization of pumpage.
  - Risk of equipment damage and serious physical injury. Heat build-up can cause rotating parts to score or seize. Observe pump for excessive heat build-up. If normal levels are exceeded, shut down and resolve.
- 

---

**NOTICE:**

Cavitation can cause damage to the internal surfaces of the pump. Ensure net positive suction head available (NPSH<sub>A</sub>) always exceeds NPSH required (NPSH<sub>3</sub>) as shown on the published performance curve of the pump.

---

### Operation under freezing conditions

---

**NOTICE:**

Do not expose an idle pump to freezing conditions. Drain all liquid that will freeze that is inside the pump and any auxiliary equipment. Failure to do so can cause liquid to freeze and damage the pump. Note that different liquids freeze at different temperatures. Some pump designs do not drain completely and may require flushing with a liquid that doesn't freeze.

---

### Temperature ratings



---

**CAUTION:**

Do not operate the pump above the rated temperature range of the magnets. This will weaken or ruin the magnets. The rated temperature is 121°C | 250°F for all sizes.

---

## 5.10 Shut down the pump



---

**WARNING:**

Precautions must be taken to prevent physical injury. The pump may handle hazardous and/or toxic fluids. Proper personal protective equipment should be worn. Pumpage must be handled and disposed of in conformance with applicable environmental regulations.

---

1. Slowly close the discharge valve.
2. Shut down and lock out the driver to prevent accidental rotation.

## 5.11 Make the final alignment of the pump and driver

---



### WARNING:

- Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.
    - Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
    - Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.
  - Misalignment can cause decreased performance, equipment damage, and even catastrophic failure of frame-mounted units leading to serious injury. Proper alignment is the responsibility of the installer and the user of the unit. Check the alignment of all drive components prior to operating the unit.
    - Follow the coupling installation and operation procedures from the coupling manufacturer.
- 

You must check the final alignment after the pump and driver are at operating temperature. For initial alignment instructions, see the Installation chapter.

1. Run the unit under actual operating conditions for enough time to bring the pump, driver, and associated system to operating temperature.
2. Shut down the pump and the driver.
3. Remove the coupling guard.  
See Remove the coupling guard in the Maintenance chapter.
4. Check the alignment while the unit is still hot.  
Refer to [4.3 Pump-to-driver alignment on page 31](#) in the Installation chapter.
5. Reinstall the coupling guard .
6. Restart the pump and driver.



---

# 6 Maintenance

## 6.1 Maintenance schedule

### Maintenance inspections

A maintenance schedule includes these types of inspections:

- Routine maintenance
- Routine inspections
- Three-month inspections
- Annual inspections

Shorten the inspection intervals appropriately if the pumped fluid is abrasive or corrosive or if the environment is classified as potentially explosive.

### Routine maintenance

Perform these tasks whenever you perform routine maintenance:

- Lubricate the bearings.
- Inspect the seal.

### Routine inspections

Perform these tasks whenever you check the pump during routine inspections:

- Check the level and condition of the oil through the sight glass on the bearing frame.
- Check for unusual noise vibration, and bearing temperatures.
- Check the pump and piping for leaks.
- Analyze the vibration.\*
- Inspect the discharge pressure.

---

**NOTICE:**

\*If equipped, temperature and vibration levels can be retrieved by using your i-ALERT® monitoring sensor and app.

---

### Three-month inspections

Perform these tasks every three months:

- Check that the foundation and the hold-down bolts are tight.
- Check the shaft alignment, and realign as required.

### Annual inspections

Perform these inspections one time each year:

- Check the pump capacity.
- Check the pump pressure.
- Check the pump power.

If the pump performance does not satisfy your process requirements, and the process requirements have not changed, then perform these steps:

1. Disassemble the pump.

2. Inspect it.
3. Replace worn parts.

## 6.2 Bearing maintenance

### Lubrication schedule

Type of bearing	First lubrication	Lubrication intervals
Oil lubricated	Change the oil after 200 hours for new bearings.	After the first 200 hours, change the oil every 4000 operating hours or every six months.



For Ex applications bearing replacement (all) is recommended after 17,500 hours of operation.



These bearing lubrication sections list different temperatures of the pumped fluid. If the pump is Ex-certified and the temperature of the pumped fluid exceeds the permitted temperature values, then consult your ITT representative.



Do not insulate or allow the bearing housings to accumulate a dust layer as this can result in excess heat generation, sparks and premature failure.

## 6.3 Required tools



### WARNING:

This pump contains extremely strong magnets. You must use non-magnetic tools and work surfaces.

---

#### Non-magnetic tools

- 9/16-inch and 3/4-inch socket wrench
- Non-metallic hammer

#### Tools

- Long T-handle hex wrench in size 3/16-inch
- 1/2-inch, 9/16-inch, and 3/4-inch sockets
- Socket wrench with a minimum extension of 4 in. (10 cm)
- Screw drivers
- Lip seal driver
- Hammer
- Three 5/16-inch x 2-inch hex capscrews
- Three 5/8-inch x 4-inch hex capscrews

## Tool kits

You can use these available tool kits in order to ease the assembly and disassembly of these pumps:

Group	Kit number	Optional tools	
		Tool number	Description
XS	R298TK04	B03309A	1 x 1½-5 bearing spider installation driver
		B04370A	1½ x2-6 bearing spider installation driver
		B03310A	Radial bearing installation tool
		A06872A	Bearing press support tool
S	R298TK01	B02496A	Bearing spider installation driver
		B02497A	Radial bearing installation tool
M	R298TK02	B03147A	Bearing spider installation driver
		B03148A	Bearing spider installation driver
		B03149A	Radial bearing installation tool
		B03189A	Magnet assembly/disassembly guide rods
L	R298TK03	B03191A	Bearing spider installation driver
		B03175A	Radial bearing installation tool
		B03149A	Radial bearing installation tool
		B03189A	Magnetic assembly/disassembly guide rods

## 6.4 Disassembly

### 6.4.1 Disassembly precautions



#### WARNING:

- Chemical hazard. You must individually decontaminate each component according to all federal, state, local, and company environmental regulations.
- A build up of gases within the pump, sealing system, or process-piping system can result in an explosive environment within the pump. Make sure that the process piping system, pump, and sealing system are properly vented prior to operation.
- Burn Hazard. Coupling may be hot. Use proper protection when handling.
- Burn Hazard. use proper protection when handling bearings.
- Avoid injury. Worn pump components can have sharp edges. Wear appropriate gloves while handling these parts.
- Risk of serious personal injury from exposure to hazardous or toxic liquids. A small amount of liquid will be present in certain areas like the seal chamber upon disassembly.
- Process fluid leaks can result in an explosive atmosphere. Follow all pump and seal assembly procedures.
- Risk of serious personal injury. Applying heat to impellers, propellers, or their retaining devices can cause trapped liquid to rapidly expand and result in a violent explosion. This manual clearly identifies accepted methods for disassembling units. These methods must be adhered to. Never apply heat to aid in their removal unless explicitly stated in this manual.
- Risk of serious physical injury or death from rapid depressurization. Ensure pump is isolated from system and pressure is relieved before disassembling pump, removing plugs, opening vent or drain valves, or disconnecting piping.

- Lifting and handling heavy equipment poses a crush hazard. Use caution during lifting and handling and wear appropriate Personal Protective Equipment (PPE, such as steel-toed shoes, gloves, etc.) at all times. Seek assistance if necessary.
- Precautions must be taken to prevent physical injury. The pump may handle hazardous and/or toxic fluids. Proper personal protective equipment should be worn. Pumpage must be handled and disposed of in conformance with applicable environmental regulations.

**CAUTION:**

- You must keep the shop area clean and free of any substances that can contaminate the magnets, such as ferrous metals.
- The magnets in this unit are extremely powerful. Beware of serious injury to fingers and hands. Keep magnetic drive components and magnetic tools apart by a minimum of 1 m | 3 ft.

**NOTICE:**

Use a bench with a non-magnetic work surface such as wood or brass when you work on the pump.

## 6.4.2 Prepare the pump for disassembly

1. Lock out power to the driver.

**WARNING:**


Failure to disconnect and lock out driver power may result in serious physical injury or death. Always disconnect and lock out power to the driver before performing any installation or maintenance tasks.

- Electrical connections must be made by certified electricians in compliance with all international, national, state, and local rules.
- Refer to driver/coupling/gear manufacturer's installation and operation manuals (IOM) for specific instructions and recommendations.


2. Shut off all valves that control flow to and from the pump.
3. Drain and flush the pump before you remove it from the piping.
4. Isolate the pump from the system and then flush the pump using a compatible liquid.
5. Disconnect all piping and auxiliary equipment.
6. For the frame-mounted pump, remove the coupling guard and coupling.
7. Remove the casing foot and frame and C-face motor-support foot bolts.
8. Remove the pump from the baseplate.
9. For the frame-mounted pump, drain the oil.
10. Decontaminate the pump:
  - a) Connect a clean-flush liquid supply to the discharge nozzle.
  - b) Collect the flushed liquid as it drains out of the drain connection.
  - c) Flush the pump in order to remove residue.


## 6.4.3 Disassemble the close-coupled pump

1. For all pumps except the V group, secure the C-face motor support and bearing frame (228) to the workbench.
2. Remove the four bolts (370B) from the C-face motor support and bearing frame (228).




- For the M and L group pumps, tighten the jacking screws (418) until the gap between the clamp ring (141C) and the C-face motor support and bearing frame is 8.89 cm | 3.50 in.
- For all pumps except the V group, grasp the suction flange of the casing and pull the casing-liquid end free from the magnet assembly.
- For the V group, grasp the motor adapter and pull it off of the casing.
- For all pumps except the SP group, remove the casing bolts (356A).
- Wrap a piece of emery cloth around the containment shell (750) and secure it with a large hose clamp.







8. Disassemble the containment shell:
  - a) Screw the C-face motor support and bearing frame bolts (370B) into the tapped holes of the clamp ring (141C) and tighten evenly in order to remove the containment shell.
  - b) Remove the O-ring (412M) from the containment shell (750) and discard it.
  - c) Remove the hose clamp and emery cloth.
9. For all groups except the SP, remove the impeller assembly (101).



10. Remove the shaft (122A) if replacement is necessary.
11. Inspect and replace the bearings, if necessary:
  - a) Inspect the bearing spider (260).  
Press it out through the suction of the casing (100) if replacement is necessary.
  - b) Use a bearing tool to press out the radial bearing (197B) from the impeller assembly (101), if replacement is necessary.




12. Inspect and replace these parts as necessary:

Pump group	Step
M and L	Inspect the rear impeller wear ring (203) and remove it if replacement is necessary.
L	Remove the retaining ring (361H). Then slide or press the magnet assembly (740A) off the impeller assembly (101). 
S, M, and SP, and V	Remove the reverse thrust bearing (197C) from the containment shell (750) if replacement is necessary.

13. When replacement of the close-coupled drive magnet assembly (740B) is required, remove and discard the nylok setscrews (222L). Use a puller and the 2 - 3/8-inch tapped holes provided in order to remove the magnet assembly from the motor shaft.

#### 6.4.4 Disassemble the frame-mounted pump


1. Place a shaft wrench on the drive shaft (122B) and remove the hex nut (355A).



**Figure 49: S, L, M, and SP groups**

2. Place three capscrews in the jacking screw holes in the magnet assembly (740B).


Group	Capscrew size
S and SP	5/16 in. by 2 in.
M and L	5/8 in. by 4 in.



**Figure 50: Magnet assembly**


3. Tighten the jacking screws evenly and in sequence until you can remove the magnet assembly (740B).
4. Remove the magnet assembly (740B) and place it away from any attracting metals.






**Figure 51: Magnet assembly removal**

5. For the L and M group pumps, remove the 5/16 in. wear ring capscrew (372Y) and the wear ring from the bottom of the bearing frame (228).




**Figure 52: L and M group wear ring removal**

6. Remove the bearing end-cover bolts (370C).




**Figure 53: Bearing end-cover bolt removal**

7. Install two bearing end-cover bolts (370C) in the jacking screw holes and tighten them evenly in order to remove the bearing end cover (109A).
8. Slide the bearing end cover (109A) backwards.  
The labyrinth oil seal (332A) slides back with the end cover.
9. Remove the labyrinth seal (332A) and the bearing end cover (109A).
10. Remove and discard the gasket (360A).
11. Remove the drive shaft (122B) with ball bearings (112) from the bearing frame (228).



12. Press the bearings (112) off the shaft and inspect them.
13. Remove the lip seal (333D).



## 6.5 Preassembly inspections

Inspect pump parts according to the following criteria before reassembly in order to make sure the pump will run properly. Replace any part that does not meet the required criteria.

### Casing



#### **WARNING:**

Risk of death or serious injury. Leaking fluid can cause fire and/or burns. Inspect and ensure gasket sealing surfaces are not damaged and repair or replace as necessary.

Inspect the casing for excessive wear, abrasive damage, cuts, or a loose liner.

**Spider bearing**

Inspect the spider bearing for cracks, chips, or scoring.

**Impeller**

- Inspect the leading and trailing edges of the vanes for erosion damage.
- Inspect the impeller for cracks and grooves in excess of 0.75 mm | 0.03 in.
- Check the impeller for blocked passages.

**Back wear ring**

Inspect the back wear ring according to the clearances in the Back wear ring clearances table.

**Table 9: Back wear ring clearances**

Size	New clearance millimeters   inches	Replace at millimeters   inches
1 x 1½-5 1½ x 2-6 1 x 1½-6 1 x 1½-6H 1 x 1½-8 1 x 1½-8H 1 x 1½-8LF 1-½ x 3-7 2 x 3-6 1½ x 3-8	No wear ring	No wear ring
3 x 4-7 3 x 4-8 2 x 3-8 1 x 2-10 1 x 2-10LF	1.52 - 1.68   0.060 - 0.066	2.3   0.090
1½ x 3-10 1½ x 3-13LF 2 x 3-10 3 x 4-10H 3 x 4-10G 4 x 6-8 4 x 6-10	1.52 - 1.78   0.060 - 0.070	2.4   0.094


**Radial bearing**

- Inspect the bearings for cracks or chips.
- Inspect the diametric bearing clearances:

	New clearance millimeters   in inches	Replace at millimeters   inches
Shaft to bearing	0.076 - 0.152   0.003 - 0.006	0.305   0.012

### Reverse and impeller thrust bearings

Inspect these bearings for cracks, chips, or scoring. If the minimum groove height is less than the minimum height recommended, then replace.



**Figure 57: 0.020 in. (0.051 cm) minimum groove height**

### Stationary shaft

Make sure the stationary shaft is free from cracks and scoring.

### Containment shell

- The containment shell must be free from scratches or cracks.
- Replace the containment shell when grooves are in excess of 0.25 mm | 0.01 in. for the outside diameter and 0.75 mm | 0.030 in. for the inside diameter.
- Make sure that the shaft fits snugly in the containment shell.

### Magnet assembly



---

#### **WARNING:**

The magnets in this unit are extremely powerful. Beware of serious injury to fingers and hands. Keep magnetic drive components and magnetic tools apart by a minimum of 1 m | 3 ft.

---

The magnets are extremely brittle. It is normal to have chips (up to 10% of the magnet surface) per MMPA standard no. 0100-90.


- Make sure that magnets are free of major cracks that extend over 50% of the surface and are free of imperfections that create loose particles.
- Replace the magnet assembly if it was exposed to pumped fluid.
- Inspect magnets for proper bonding to the carrier.

### Bearing frame - frame-mounted version only

- Inspect the frame and frame foot for cracks.
- Inspect the frame and rub ring for corrosion or pitting if parts have been exposed to pumped fluid.
- Inspect the bearing frame bores. The maximum acceptable bore is:

- S group: 62.024 mm | 2.4419 in.
- M and L groups: 72.017 mm | 2.8353 in.
- Inspect the ball bearings for contamination and damage.
- Inspect the bearing end cover for cracks and pits.
- Make sure that the gasket surface is clean.
- Replace the lip seal.
- Inspect the shaft for cracks and scoring.

### Inspection locations



## 6.6 Reassembly

### 6.6.1 Reassembly precautions



#### WARNING:

Explosion risk. Rubbing could lead to excess heat generation and sparks. Rotate the shaft by hand to make sure it rotates smoothly and that there is no rubbing.



#### CAUTION:

- The magnets in this unit are extremely powerful. Beware of serious injury to fingers and hands. Keep magnetic drive components and magnetic tools apart by a minimum of 1 m | 3 ft.
- Use a non-magnetic socket and wrench.

#### NOTICE:


- Use caution when you use an hydraulic press because you cannot feel when the bearing hits the bottom of the bore.

- Do not hammer the magnet assembly onto the shaft. This will damage the ball bearings.
  - Pressing the radial bearings into the impeller can cause some ETFE to peel. If this occurs, press out the bearings, remove any ETFE filings, and then press the bearings back into the impeller.
  - There are several methods you can use to install bearings. The recommended method is to use an induction heater that heats and demagnetizes the bearings.
  - You may need to lightly press the shaft with bearings into the bearing frame. It is important that you press the bearings in by putting a sleeve on the inner race of the outboard ball bearing.
  - Make sure that the shaft O-ring, grooves, shaft keyways, and keyway in the frame are free of burrs.
- 

Since the bolt pattern for the bearing end cover (109A) is not symmetric, the bearing end cover gasket (360A) and bearing end cover (109A) can only go on one way. This ensures that the oil return slot will always be down.


### 6.6.2 Reassemble the rotary assembly

1. For the L group, complete these steps:
  - a) Install the O-ring (496G) into the driven magnet assembly (740A).
  - b) Lubricate the O-ring (496G) with Parker O-ring lube or an equivalent lube.
  - c) Press the driven magnet assembly (740A) onto the impeller assembly (101).
  - d) Install the retaining ring (361H) into the groove of the impeller assembly (101).




**Figure 58: 3298 L group impeller**

2. For all groups except XS, install the key:
  - a) Slide key (178S) into impeller (101).
  - b) Use a center punch to stake the impeller at the end of the key in order to hold the key in place.




**Figure 59: 3298 S, M, and L groups, SP3298, and V3298**

3. Install the radial bearing into the impeller:
  - a) Lubricate the outside of the radial bearing.
  - b) Use the bearing installation tool to press the radial bearing (197B) into the impeller.
  - c) Support the impeller with the bearing press support tool.
  - d) Line up the keyway in the bearing with the key in the impeller.




**Figure 60: XS group**


4. For all groups except XS, slide the bearing spacer (157A) into the impeller and then press the second radial bearing (197B) into the impeller.



5. For the L group, press the impeller wear ring (203) into the impeller assembly.
6. Turn the impeller over and install the impeller thrust bearing (197D). Make sure to align the two slots in the impeller thrust bearing with the two tabs in the impeller.




7. For all groups except XS, slide the reverse thrust bearing onto the shaft.
8. Press the shaft (122A) into the containment shell (750).
9. Coat the O-ring (412M) with an O-ring lubricant and insert it in the containment shell (750). The lubricant is used to help the O-ring remain in place.



10. For the SP3298, complete these steps:
  - a) Place the backplate (444) face down on the work surface.
  - b) Place the containment shell with the reverse thrust bearing in the backplate.




- c) Place a clamp ring (141C) over the containment shell and secure with clamp ring bolts (356A).
- d) Coat the O-ring (412V) with an O-ring lubricant. Insert the O-ring in the backplate. The lubricant helps the O-ring remain in place.



**Figure 67: SP3298**


11. Slide the impeller assembly (101) onto the shaft.




**Figure 68: 3298 XS, S, M, and L groups, and V3298**

**Figure 69: SP group**


12. Press the spider (260) into the volute insert (100U) with the spider tool. Then press the volute insert with the spider into the casing (100).



**Figure 70: 3298**





**Figure 71: V3298**




**Figure 72: SP3298**


13. Check the total travel of the rotary assembly:

Pump group	Travel between A and B in millimeters   inches
3298 XS	0.66 - 2.11 mm   0.026 - 0.083 in.
3298 S, V3298 S, and SP3298	0.33 - 2.5 mm   0.013 - 0.100 in.
3298 M and L, and V3298 M	0.51 - 2.67 mm   0.020 - 0.105 in.






14. For the 3298 and V3298, install these items into the casing:
- Install the containment shell and impeller assembly into the casing (100). Use care that the O-ring (412M) remains in place.
  - Install the clamp ring (141C) into the casing (100) with the hex capscrews (356A).



15. Install the impeller assembly and backplate/clamp ring/containment shell assembly into the casing (100) using casing bolts (372V). Make sure that the O-ring remains in place.




**Figure 79: SP3298**

16. Set the partially-built assembly aside and away from any attracting metals.
- Continue the assembly with the close coupled or frame mounted version of assembly as described in this chapter.


### 6.6.3 Reassemble the close-coupled pump

1. Install four expansion plugs (408Z) into the C-face motor support (228) by tapping on the plug with a 5/8 in. rod.  
Expansion plugs are not used for the 182TC - 256TC and 324TSC motor frames.




**Figure 80: Close coupled frame**

2. Set the C-face motor support (228) on the motor and install four screws (371).
3. Slide the key (178Y) into the motor shaft keyway.
4. Install two setscrews (222L) into the magnet assembly (740B).




**Figure 81: Drive magnet**

5. Slowly drop in the magnet assembly until the shim rests on the face of the C-face motor support.



**Figure 82: Drive magnet assembly**



6. Rotate the magnet assembly (740B) to line up the key (178Y) with the access hole on the C-face motor support (228).
7. Tighten the first setscrew (222L) through the access hole.
8. Remove the shim and rotate the magnet assembly 90° in order to access the other setscrew.
9. Tighten the setscrew.

### 6.6.4 Reassemble the frame-mounted pump



#### CAUTION:

Risk of physical injury from hot bearings. Wear insulated gloves when using a bearing heater.


1. Install the ball bearings (112) on the shaft (122B) at both ends.
  - a) Heat the bearings to 100°C | 212°F in an oil bath or with a bearing heater.
  - b) Install the properly-heated thrust bearing (112) onto the shaft.

If necessary, position a tube against the inner ring of the bearing and gently tap the tube with a hammer in order to force the bearing onto the shaft. Hold the outer ring of the bearing in order to prevent vibration damage to the bearing .


2. Install the lipseal (333D) in the bearing frame (228).

#### NOTICE:

- Ensure that the pipe threads are clean. Apply thread sealant to the plugs and fittings. Failure to do so may result in oil leaks and equipment damage.
- There are several methods you can use to install bearings. The recommended method is to use an induction heater that heats and demagnetizes the bearings. Bearings can get hot and can cause physical injury.




**Figure 85: Ball bearing installation**




**Figure 86: Bearing frame**

3. Bolt or clamp the bearing frame (228) to the work bench.




**Figure 87: Bearing frame secured to bench**

4. Install the shaft (122B) with ball bearings (112) into the bearing frame (228). Point the threaded end of the shaft towards the magnets.




**Figure 88: S group bearing installation**

5. For the M and L group, install the wave washer.




**Figure 89: M and L group bearing installation**

6. Install the bearing-end cover gasket (360A) and bearing end cover (109A) with hex capscrews (370C).



**Figure 90: Bearing frame assembly**


7. Press the labyrinth seal (332A) into the end cover (109A):
  - a) Make sure that the O-rings are in grooves of labyrinth seal.
  - b) Orient the expulsion ports to the 6 o'clock position and press the seal into the bearing end cover (109A) until it is shouldered against the end cover. No adjustment is necessary.
8. Install the key (178Y) on the shaft (122B).



**Figure 91: Drive magnet assembly**

9. Install the magnet assembly (740B) onto the shaft (122B).
10. Place a shaft wrench on the drive shaft (122B). Install a hex nut (355A) and tighten the nut per the Bolt torque values table in the Reassembly section of the Maintenance chapter.
11. For the M and L groups, complete these steps:
  - a) Install the rub ring (144A) into the bearing frame (228).
  - b) Line up the hole in the rub ring with the tapped hole in the frame (228) by using the scribed mark on the rub ring to reference the tapped hole in the frame.
  - c) Lightly tap the rub ring (144A) with a rubber mallet until it shoulders into the bearing frame (228).
  - d) For the M and L groups, install a 5/16 in. hex capscrew (372Y) into the bottom of the frame (228). This capscrew prevents the rub ring (144A) from rotating during pump operation.






**Figure 92: M and L group drive magnet assembly**

### 6.6.5 Complete the reassembly (close-coupled and frame-mounted pumps)


1. For all groups except XS, install the gasket (360W) into the clamp ring (141C).
2. Bolt the C-face support and frame (228) to the work bench.
3. For the M and L groups, install guide rods:
  - a) Tighten the jacking screws (418) until they are fully extended through the C-face support and frame flange (228).

Check that extension from the frame is approximately 8.89 cm | 3.50 in.



**Figure 93: Bearing frame with guide rods**

- b) Install the two guide rods (B03189A) into the clamp ring (141C). These rods help you guide the casing assembly into the C-face support and frame (228), which contains the drive magnets (740B).



- i. Casing assembly
- ii. Guide rods

**Figure 94: Casing assembly with guide rods**

4. Slide the casing assembly into the C-face support and bearing frame assembly:

If your pump group is...	Then...
XS or S	<ol style="list-style-type: none"> <li>1. Hold the casing firmly by the suction flange and suction side of the discharge flange. Keep hands away from the clamp ring in order to avoid pinched fingers.</li> <li>2. Slowly insert the casing in order to avoid damage.</li> </ol>
M or L	<ol style="list-style-type: none"> <li>1. Position the casing assembly so that the two guide rods are engaged into two of the C-face support and frame capscrew holes and the jacking screws (418) contact the casing assembly clamp ring (141C).</li> <li>2. Loosen the jacking screws (418) and slowly draw the casing assembly into the C-face support and bearing frame assembly.</li> </ol> <p>Keep hands away from clamp ring to avoid pinched fingers.</p> <div style="text-align: center;"> </div> <ul style="list-style-type: none"> <li>1. Casing assembly</li> <li>2. Guide rods</li> </ul>

5. Secure with four hex capscrews (370B) and tighten.

### 6.6.6 Assembly references

### 6.6.6.1 Bolt torque values

Location	Dry threads torque in Nm   ft-lbs
Hex nut – 355A	40   30
Clamp ring screws – 356A	40   30
Support / frame screws – 370B	40   30
Cover-to-frame – 370C	40   30
Drain screws – 426A XS and S	19   14
Drain screws – 426A M and L	25   18

### 6.6.6.2 Impeller trimming guidelines

#### Precautions


- Do not chuck the impeller assembly.
- Do not make cuts that are larger than 0.127 cm | 0.050 in.
- Do not over-tighten the arbor screw because this can crack the carbon bearings.

#### Required tools

Group	Sizes		Arbor Tool
XS	1x1½-5		A06785A01
	1½ x 2-6		A06785A08
S	1 x 1½-6	1 x 1½-8LF	A06785A02
	1 x 1½-6H	1½ x 3-7	
	1 x 1½-8	1½ x 3-8	
	1 x 1½-8H	2 x 3-6	
M and L	2 x 3-8	2 x 3-10	A06785A03
	3 x 4-7	3 x 4-10G	
	3 x 4-8		
	1 x 2-10	3 x 4-10H	
	1 x 2-10LF	4 x 6-10	
	1½ x 3-10	4 x 6-8	
	1½ x 3-13LF		

You can use nylon impeller arbor sleeves in place of bearings:

- XS group–B04674A01
- S group–B04676A02
- M group–B04676A03
- L group–B04676A04



1. Small radius 0.005 to 0.002
2. 45° rake angle


**Figure 95: Recommended cutting tool**

Tool features:


- 200 to 300 RPM
- 300 to 500 ft./min
- High-speed steel tool
- Light hand feed

#### **Trimming guidelines**

- Make sure that the arbor runs within 0.002 TIR.
- Tighten the screw only enough to turn the impeller without it slipping.
- The allowed front shroud TIR is 0.152 cm | 0.060 in.
- For the XS impeller, trim both the front and back shrouds and the vanes to a minimum diameter of 9.53 cm | 3.75 in.
- When you trim between 7.62 cm | 3.00 in. and 9.53 cm | 3.75 in., trim only the front shroud and the vanes.


**Trimming examples**

1. Impeller
2. Steel washer with rubber bond
3. Paper gasket
4. Arbor

**Figure 96: XS group**

1. Steel washer with rubber bond
2. Socket head capscrew
3. Impeller
4. Paper gasket
5. Arbor

**Figure 97: S and M groups**



1. Steel washer with rubber bond
2. Socket head capscrew
3. Impeller
4. Paper gasket
5. Arbor

**Figure 98: L group**


### 6.6.6.3 SP3298 volute insert trimming guidelines

#### Trimming guidelines

Do not make cuts larger than 0.127 cm | 0.050 in.

Use arbor tool C06820A for SP3298 size 1x1.5-6 and C06821A for SP3298 size 2x3-6.

Make sure that the arbor runs within 0.005 cm | 0.002 in. TIR.



1. Volute insert
2. Arbor


#### Cutwater trimming guidelines

Machine the cutwater to full depth using radius dimension "R" as shown in the Cutwater radius table.

Use arbor tool C06820A for SP3298 size 1x1.5-6 and tool C06821A for SP3298 size 2x3-6.

**Table 10: Cutwater radius**

Impeller diameter in centimeters   inches	"R" +/- 0.25 mm   0.010 inches
12.70   5.00	6.510   2.563
13.00   5.12	6.668   2.625
13.34   5.25	6.827   2.688
13.67   5.38	6.985   2.750
13.97   5.50	7.145   2.813
14.27   5.62	7.303   2.875
14.61   5.75	7.463   2.938
14.94   5.88	7.620   3.000
15.24   6.00	7.780   3.063
15.39   6.06	7.859   3.094



1. Steel washer with rubber bond
2. Hex flange nut
3. Volute insert
4. Paper gasket
5. Arbor

## 6.7 Spare parts

### Liquid end

Part	Part number	Material	Quantity
Containment shell O-ring	412M	Standard – viton Optional – EDPM Optional – PTFE-encapsulated viton	1
Gasket – clamp ring	360W	Aramid fiber / EDPM binder	1
Bearing spider	260	Tefzel / silicon carbide	1
Impeller bearing	178S	Tefzel	1
Radial bearing	197B	Standard – carbon Optional – silicon carbide Optional – DryGuard® silicon carbide	2
Reverse thrust bearing	197C	Carbon-filled PTFE	1
Impeller thrust bearing	197D	Standard – carbon filled PTFE Optional – silicon carbide Optional – DryGuard® silicon carbide	1
Rear impeller wear ring (M and L groups)	203	Standard – carbon filled PTFE	1

### Power end – frame-mounted

Part	Part number	Material	Quantity
End cover gasket	360A	Varnished Kraft	1
Labyrinth seal	332A	Carbon filled PTFE	1
Ball bearing	112	Steel	2
Lip seal	333D	Buna rubber	1
Hex flange nut	355A	Steel	1
L group impeller O-ring	496G	Standard – viton Optional – EDPM Optional – PTFE encapsulated viton	1

### 6.7.1 Repair kits

Size	Repair cartridge <sup>1</sup>			Power end kit <sup>2</sup>
	Carbon	Silicon carbide	DryGuard®	
XS				
1 x 1.5-5	C298X1500CV000	C298X1500SV000	C298X1500FV000	N/A
1.5 x 2-6	C298X1560CV000	C298X1560SV000	C298X1560FV000	N/A
S				
1 x 1.5-6	C298S1600CV000	C298S1600SV000	C298S1600FV000	R298PKS
1 x 1.5-6H	C298S6H00CV000	C298S6H00SV000	C298S6H00FV000	R298PKS
1 x 1.5-8	C298S1800CV000	C298S1800SV000	C298S1800FV000	R298PKS
1 x 1.5-8H	C298S8H00CV000	C298S8H00SV000	C298S8H00FV000	R298PKS
1 x 1.5-8LF	C298S18L0CV000	C298S18L0SV000	C298S18L0FV000	R298PKS
1.5 x 3-7	C298S1570CV000	C298S1570SV000	C298S1570FV000	R298PKS
2 x 3-6	C298S2600CV000	C298S2600SV000	C298S2600FV000	R298PKS




Size	Repair cartridge <sup>1</sup>			Power end kit <sup>2</sup>
	Carbon	Silicon carbide	DryGuard®	
M				
1.5 x 3-8	C298M1580CV000	C298M1580SV000	C298M1580FV000	R298PKML
1 x 2-10	C298M1100CV000	C298M1100SV000	C298M1100FV000	R298PKML
1 x 2-10LF	C298M11L0CV000	C298M11L0SV000	C298M11L0SV000	R298PKML
2 x 3-8	C298M2800CV000	C298M2800SV000	C298M2800FV000	R298PKML
3 x 4-7	C298M3700CV000	C298M3700SV000	C298M3700FV000	R298PKML
3 x 4-8	C298M3800CV000	C298M3800SV000	C298M3800FV000	R298PKML
L				
1.5 x 3-10	C298L1510CV000	C298L1510SV000	C298L1510FV000	R298PKML
2 x 3-10	C298L2100CV000	C298L2100SV000	C298L2100FV000	R298PKML
3 x 4-10H	C298L3100CV000	C298L3100SV000	C298L3100FV000	R298PKML
3 x 4-10G	C298L310GCV000	C298L310GSV000	C298L310GFV000	R298PKML
4 x 6-10	C298L4100CV000	C298L4100SV000	C298L4100FV000	R298PKML
4 x 6-8	C298L4600CV000	C298L4600SV000	C298L4600FV000	R298PKML
1.5 x 3-13LF	C298L13L0CV000	C298L13L0SV000	C298L13L0FV000	R298PKML
<p><sup>1</sup>The repair cartridge is a fully-assembled kit with a trimmed impeller and includes the spider, thrust bearing, bearing spacer, bearing key, radial bearings, rear impeller wear ring (if required), shaft, reverse thrust bearing, and the containment shell. L groups also include a magnet retaining ring and a support o-ring.</p> <p><sup>2</sup>The power-end repair kits include the ball bearings, drive carrier key, lip seal, hex flange nut, bearing-end cover gasket, frame gasket, and the labyrinth O-rings.</p>				

# 7 Troubleshooting

## 7.1 Operation troubleshooting

Symptom	Cause	Remedy
The pump is not delivering liquid.	The pump is not primed.	For the 3298 and V3298, reprime the pump and check that the pump and suction line are full of liquid. For the SP3298: <ul style="list-style-type: none"> <li>• Add an initial charge to the casing.</li> <li>• Since the suction lift is greater than the maximum allowed, raise the sump level.</li> </ul>
	The suction line is clogged.	Check the suction line pressure. If it is low, locate and remove any obstructions.
	The impeller is clogged.	Disassemble the impeller and remove the blockage.
	The magnet is de-coupling.	Shut down the pump and check the temperature and viscosity of the pumped fluid.
The suction line is clogged.	Check the suction line pressure. If it is low, locate and remove any obstructions.	
The impeller is clogged.	Disassemble the impeller and remove the blockage.	
The magnet is de-coupling.	Shut down the pump and check the temperature and viscosity of the pumped fluid. Check the magnets with a breakaway torque test.	
The pump is not producing rated flow or head.	There is an air leak in the suction line.	Check for leaks and repair the lines.
	The impeller is partly clogged.	Back flush the pump to clean the impeller.
	The impeller rings are worn.	Replace the defective ring as required.
	There is insufficient suction head.	Make sure that the suction line shutoff valve is fully open and the line is unobstructed. Check the suction pressure.
	The impeller is either worn or broken.	Inspect and replace the impeller if necessary.
	The rotation is wrong.	Correct the wiring.
Pump starts and then stops pumping.	The pump is not primed correctly.	Reprime the pump.
	There is an air leak in the suction line.	Check for leaks and correct.
	The magnet is de-coupling.	Shut down the pump. Check the temperature and viscosity of the pumped fluid.
	There are either air or vapor pockets in the suction line.	Rearrange the piping to eliminate air pockets.
The bearings run hot.	The bearings are not lubricated properly.	Check the suitability and level of the lubricant.
	The lubricant is cooling.	Check the cooling system.
	The pump is not aligned properly.	Check the pump alignment.
Pump is noisy or vibrates.	The pump or driver is not aligned properly.	Align the shafts.

Symptom	Cause	Remedy
	There is a partially-clogged impeller causing the imbalance.	Disassemble the impeller and remove the blockage.
	There is a broken or bent impeller or shaft.	Replace as required.
	The base is not rigid enough.	Tighten the pump and motor hold-down bolts or adjust the stilts. Then check the grout.
	The suction or discharge piping is not anchored or properly supported.	Anchor the piping per the Hydraulic Institute Standards recommendations (Edition 14, centrifugal pump section).
	The pump is cavitating.	Increase the NPSH available.
The motor requires excessive power.	The head is lower than the rating and the pump has too much liquid.	Install a throttle valve.
	The liquid is heavier than expected.	Check the specific gravity and viscosity.
	The head is higher than the rating, which is at capacity.	Check the impeller diameter.
	The rotating parts are binding or are severely worn.	Check the internal wearing parts for proper clearances.
	The motor rotation is incorrect.	Correct the wiring.
The condition monitoring device shuts down the pump.	The sleeve and thrust bearings are damaged.	Replace as required.
	There is a plugged recirculation circuit.	Disassemble and remove the blockage. Then determine and correct the cause of the blockage.
	There is recirculation liquid vaporization.	Correct all of these as necessary: <ul style="list-style-type: none"> <li>• Check the actual liquid temperature versus the design temperature.</li> <li>• Check the actual NPSH available versus the design.</li> <li>• Check the minimum flow requirement for the pump size.</li> </ul>
	The containment shell is damaged.	Replace as required.
	The magnets are de-coupling.	Check the temperature and viscosity of the pumped fluid.
	The pump is running dry.	<ul style="list-style-type: none"> <li>• Check the control device for proper operation.</li> <li>• Check the suction line for blockage.</li> <li>• Reprime the pump.</li> </ul>
	There is excessive motor power.	The system head is lower than the rating and pumps too much liquid. Check the rotating parts for binding and wear. The liquid is heavier than expected.
There is a significant increase in heat generation.	<p>There is either insufficient lubrication or you ran the liquid lubricated bearing surfaces dry. The lack of cooling flow through the pump also causes significant increases in bearing temperature. This temperature increase causes damage to the surrounding parts. See the Increase in heat generation figure for details.</p> <ul style="list-style-type: none"> <li>• Install a dry run protection device like a power monitor.</li> <li>• Modify the process system or controls in order to eliminate the dry run operation.</li> <li>• Change the bearing material to DryGuard® coated silicon carbide if silicon carbide bearings were initially installed in the pump.</li> </ul>	



1. Check to see if the plastic that surrounds the outboard thrust bearing is melted.
2. Check to see if the plastic that surrounds the carbon or silicon carbide impeller radial bearings is melted.
3. Check to see if the plastic that surrounds the inboard thrust bearings is melted.
4. If the impeller seizes on the shaft due to excessive heat, the shaft can spin in the shaft spider, which wears the inside diameter of the shaft spider.

**Figure 99: Increase in heat generation**


## 7.2 Alignment troubleshooting

Symptom	Cause	Remedy
Horizontal (side-to-side) alignment cannot be obtained (angular or parallel).	The driver feet are bolt-bound.	Loosen the pump's hold-down bolts, and slide the pump and driver until you achieve horizontal alignment.
	The baseplate is not leveled properly and is probably twisted.	<ol style="list-style-type: none"> <li>1. Determine which corners of the baseplate are high or low.</li> <li>2. Remove or add shims at the appropriate corners.</li> <li>3. Realign the pump and driver.</li> </ol>
Vertical (top-to-bottom) alignment cannot be obtained (angular or parallel).	The baseplate is not leveled properly and is probably bowed.	<ol style="list-style-type: none"> <li>1. Determine if the center of the baseplate should be raised or lowered.</li> <li>2. Level screws equally at the center of the baseplate.</li> <li>3. Realign the pump and driver.</li> </ol>


# 8 Parts List and Cross-Sectionals

## 8.1 3298 XS group close-coupled pump

With NEMA motor



**With IEC motor**




**Parts list**

Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-filled Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: DryGuard® silicon carbide
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
141C	Clamp ring	Ductile iron
178Y	Key – motor to magnet assembly	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon graphite Optional: silicon carbide Optional: DryGuard® silicon carbide
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon/glass-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
222L	Setscrew	Steel
228	C-face motor support	Cast iron

Item	Part name	Material
241 <sup>2</sup>	Frame foot	Ductile iron
351G	Gasket – casing drain	Gylon
356A	Hex capscrew – clamp ring to casing	304 SS
358	Cover – drain	Steel
370B	Hex capscrew – support to clamp ring	304 SS
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE – encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
426A	Hex capscrew – drain cover	304 SS
492A	Plug – access hole	Steel
740B	Drive carrier	Carbon-filled Tefzel / fiber-reinforced vinylester
750	Containment shell	Carbon-filled Tefzel / Fiber-reinforced Vinylester
<sup>1</sup> Recommended spare parts		
<sup>2</sup> Not supplied on size 1.5 x 2-6 with the 213/215TC motor frame.		

## 8.2 3298 S group frame-mounted pump

### S group frame-mounted drawing



### S group frame-mounted parts list


Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-filled Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: carbon-filled Tefzel / DryGuard® silicon carbide

Item	Part name	Material
109A	End cover	Ductile iron
112 <sup>1</sup>	Ball bearings	Steel
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
122B	Drive shaft	Steel
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial bearings	PTFE
178S <sup>1</sup>	Key – impeller to radial bearings	PTFE
178Y	Key – drive carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
228	Frame – bearing	Cast iron
332A <sup>1</sup>	Labyrinth seal – outboard	Brass
333D <sup>1</sup>	Oil lip seal – inboard	Buna rubber
351G <sup>1</sup>	Gasket – casing drain	Gylon
355A <sup>1</sup>	Hex nut	Steel
356A	Hex capscrew – clamp ring to casing	304 SS
358	Flange – casing drain	Steel
360A <sup>1</sup>	Gasket – end cover to frame	Varnished Kraft
360W	Gasket – frame to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – frame to clamp ring	304 SS
370C	Hex capscrew – end cover	304 SS
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
426A	Hex capscrew – casing drain	304 SS
740B	Drive magnet assembly	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
<sup>1</sup> Recommended spare parts		




## 8.3 3298 S group close-coupled pump

### With NEMA motor



### With IEC motor



**S group close-coupled parts list**


Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-filled Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: carbon-filled Tefzel / DryGuard® silicon carbide
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial bearings	PTFE
178S <sup>1</sup>	Key – impeller to radial bearings	PTFE
178Y	Key – motor to carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon graphite Optional: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
222L	Setscrew	Steel
228	Motor support – close coupled	Cast iron
351G <sup>1</sup>	Gasket – casing drain	Gylon
356A	Hex capscrew – clamp ring to casing	304 SS
358	Flange – casing drain	Steel
360W <sup>1</sup>	Gasket – motor support to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – motor support to clamp ring	304 SS
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
426A	Hex capscrew – casing drain	304 SS
492A	Access hole plug	Steel
740B	Drive magnet assembly	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
<sup>1</sup> Recommended spare parts		

Item	Part name	Material
228	Frame, close coupled (IEC)	Ductile iron
333L	Setscrew	304 SS
371	Hex capscrew – motor to frame	Carbon steel
388T	Hex capscrew – adapter to frame <sup>1</sup>	Carbon steel
408A	Plug – drain	Carbon steel
492A	Plug – access hole	Carbon steel

Item	Part name	Material
503	Ring – adapter <sup>1</sup>	Cast iron
742B	Ring – centering <sup>2</sup>	Carbon steel
<sup>1</sup> Used with motor frame 132 and 160 only.		
<sup>2</sup> Used with motor frames 80 and 90 only.		

## 8.4 3298 M group frame-mounted pump

### M group frame-mounted drawing




### M group frame-mounted parts list

Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-filled Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: carbon-filled Tefzel / DryGuard® silicon carbide
109A	End cover	Ductile iron
112 <sup>1</sup>	Ball bearings	Steel
113A	Plug, oil fill	Steel
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
122B	Drive shaft	Steel
141C	Clamp ring	Ductile iron
144A	Rub ring	Cast iron

Item	Part name	Material
157A	Bearing spacer – radial	PTFE
178S <sup>1</sup>	Key – impeller to bearings	PTFE
178Y	Key – drive carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon graphite Optional: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
203 <sup>1</sup>	Wear ring – rear impeller	Carbon-filled PTFE
228	Frame – bearing	Cast iron
241	Frame foot	Cast iron
319	Sight window	Steel / glass
332A	Labyrinth seal	Carbon-filled PTFE
333D <sup>1</sup>	Lip seal	Buna rubber
351G <sup>1</sup>	Gasket – casing drain	Gylon
355A	Flanged hex nut	Steel
356A	Hex capscrew – clamp ring to casing	304 SS
358	Flange – casing drain	Steel
360A <sup>1</sup>	Gasket – end cover to frame	Varnished Kraft
360W <sup>1</sup>	Gasket – frame to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – frame to clamp ring	304 SS
370C	Hex capscrew – end cover to frame	304 SS
370F	Hex capscrew – frame foot	304 SS
372Y	Hex capscrew – frame to rub ring	304 SS
408A	Plug – drain	Steel
408J	Plug – oiler	Steel
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE Optional: Chemraz 505 Optional: Kalrez 4079
418	Hex tap bolt – jacking	304 SS
426A	Hex capscrew – casing drain	304 SS
529 <sup>1</sup>	Washer – wave spring	Steel
740B	Drive carrier	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
<sup>1</sup> Recommended spare parts		

## 8.5 3298 M group close-coupled pump

### M group close-coupled drawing




### M group close-coupled parts list


Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-filled Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: carbon-filled Tefzel / DryGuard® silicon carbide
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial	PTFE
178S <sup>1</sup>	Key – impeller to bearings	PTFE
178Y	Key – motor to carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon graphite Optional: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
203 <sup>1</sup>	Wear ring – rear	Carbon-filled PTFE
222L	Setscrew	Steel
228	Frame – close coupled	Cast iron
351G <sup>1</sup>	Gasket – casing drain	Gylon

Item	Part name	Material
356A	Hex capscrew – clamp ring to casing	304 SS
358	Flange – casing drain	Steel
360W <sup>1</sup>	Gasket – frame support to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – frame to clamp ring	304 SS
370F	Hex capscrew – frame foot	304 SS
371	Hex capscrew – frame to motor	304 SS
408A	Plug – drain	Steel
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE- encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
418	Hex tap bolt – jacking	304 SS
426A	Hex capscrew – casing drain	304 SS
492A	Plug – access hole	Steel
740B	Drive carrier	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
<sup>1</sup> Recommended spare parts		

## 8.6 3298 L group frame-mounted pump

L group frame-mounted drawing





**Figure 100: Two-piece impeller**

### L group frame-mounted parts list

Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-fiber-reinforced Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: carbon-filled Tefzel / DryGuard® silicon carbide
109A	End cover	Ductile iron
112 <sup>1</sup>	Ball bearings	Steel
113A	Plug – oil fill	Steel
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
122B	Drive shaft	Steel
141C	Clamp ring	Ductile iron
144A	Rub ring	Cast iron
157A	Bearing spacer – radial	PTFE
178S <sup>1</sup>	Key – impeller to bearings	PTFE
178Y	Key – drive carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon graphite Optional: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing, reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
203 <sup>1</sup>	Wear ring – rear impeller	Carbon-filled PTFE
228	Frame – bearing	Cast iron
241	Frame foot	Cast iron
319	Sight window	Steel / glass
332A	Labyrinth seal	Carbon-filled PTFE
333D <sup>1</sup>	Lip seal	Buna rubber
351G <sup>1</sup>	Gasket – casing drain	Gylon
355A	Flanged hex nut	Steel
356A	Hex capscrew – clamp ring to casing	304 SS
358	Flange – casing drain	Steel
360A <sup>1</sup>	Gasket – end cover to frame	Varnished Kraft
360W <sup>1</sup>	Gasket – frame to clamp ring	Aramid fibers with EPDM


8.6 3298 L group frame-mounted pump

Item	Part name	Material
361H	Retaining ring	PTFE-encapsulated silicone
370B	Hex capscrew – frame to clamp ring	304 SS
370C	Hex capscrew – end cover to frame	304 SS
370F	Hex capscrew – frame foot	304 SS
372Y	Hex capscrew – frame to rub ring	304 SS
408A	Plug – drain	Steel
408J	Plug – oiler	Steel
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE Optional: Chemraz 505 Optional: Kalrez 4079
418	Hex tap bolt – jacking	304 SS
426A	Hex capscrew – casing drain	304 SS
496G <sup>1</sup>	O-ring – drive magnet assembly	Standard: Viton Optional: EPDM Optional: PTFE Optional: Chemraz 505 Optional: Kalrez 4079
529 <sup>1</sup>	Washer – wave spring	Steel
740A	Drive magnet assembly	Tefzel / neodymium iron
740B	Drive carrier	Cast iron / neodymium iron
750	Containment shell	Carbon-filled Tefzel / fiber-reinforced vinylester
<sup>1</sup> Recommended spare parts		



## 8.7 3298 L group close-coupled pump

### L group close-coupled drawing



**Figure 101: Two-piece impeller**


### L group close-coupled parts list

Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Carbon-filled Tefzel
260 <sup>1</sup>	Bearing spider	Standard: carbon-filled Tefzel / silicon carbide Optional: carbon-filled Tefzel / DryGuard® silicon carbide
122A	Stationary shaft	Standard: silicon carbide Optional: DryGuard® silicon carbide
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial	PTFE
178S <sup>1</sup>	Key – impeller to bearings	PTFE
178Y	Key – motor to carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon graphite Optional: silicon carbide

Item	Part name	Material
		Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
203 <sup>1</sup>	Wear ring – rear	Carbon-filled PTFE
222L	Setscrew	Steel
228	Frame – close coupled	Cast iron
241	Frame foot	Cast iron
351G <sup>1</sup>	Gasket – casing drain	Gylon
356A	Hex capscrew – clamp ring to casing	304 SS
358	Flange – casing drain	Steel
360W <sup>1</sup>	Gasket – frame support to clamp ring	Aramid fibers with EPDM
361H	Retaining ring	PTFE-encapsulated silicone
370B	Hex capscrew – frame to clamp ring	304 SS
370F	Hex capscrew – frame foot	304 SS
371	Hex capscrew – frame to motor	304 SS
408A	Plug – drain	Steel
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
418	Hex tap bolt – jacking	304 SS
426A	Hex capscrew – casing drain	304 SS
492A	Plug – access hole	Steel
496G	O-ring – drive magnet assembly	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
740A	Drive magnet assembly	Tefzel / neodymium iron
740B	Drive carrier	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
<sup>1</sup> Recommended spare parts		

## 8.8 SP3298 S group frame-mounted pump in sizes 1 x 1-1/2 - 6

### SP3298 S group frame-mounted drawing



### SP3298 S group frame-mounted parts list


Item	Part name	Material
100	Casing	Ductile iron / Tefzel
100U	Volute insert	Carbon-filled Tefzel
101	Impeller assembly	Tefzel
260 <sup>1</sup>	Bearing spider	Tefzel / silicon carbide
109A	End cover	Ductile iron
112 <sup>1</sup>	Ball bearings	Steel
113A	Plug – oil fill	Steel
122A	Stationary shaft	Silicon carbide
122B	Drive shaft	Steel
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial	PTFE
178S <sup>1</sup>	Key – impeller to radial bearings	Tefzel
178Y	Key – drive carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon Optional: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
203	Wear ring – rear	Carbon-filled PTFE
228	Frame – bearing	Cast iron

8.8 SP3298 S group frame-mounted pump in sizes 1 x 1-1/2 - 6


Item	Part name	Material
319	Sight window	steel / glass
332A <sup>1</sup>	Labyrinth seal	Carbon-filled PTFE
333D <sup>1</sup>	Lip seal	Buna rubber
355A <sup>1</sup>	Flanged hex nut	Steel
356A	Hex capscrew – clamp ring to backplate	304 SS
360A <sup>1</sup>	Gasket – end cover to frame	Varnished Kraft
360W	Gasket – frame to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – frame to clamp ring	304 SS
370C	Hex capscrew – end cover to frame	304 SS
372V	Hex capscrew – backplate to casing	304 SS
408A	Plug – drain	Steel
408J	Plug – oiler	Steel
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
412V	O-ring – backplate	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
444	Backplate	Ductile iron / Tefzel
740B	Drive magnet assembly	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
811	Cover – casing drain	Carbon steel
811A	Cover – casing fill	Carbon steel
811B	Gasket – casing drain	Non-asbestos packing
811C	Gasket – casing fill	Non-asbestos packing
811D	Hex capscrew – drain cover	304 SS
<sup>1</sup> Recommended spare parts		

## 8.9 SP3298 S group close-coupled pump in sizes 1 x 1-1/2 - 6

SP3298 S group close-coupled drawing, with NEMA motor



SP3298 S group close-coupled drawing, with IEC motor



**SP3298 S group close-coupled drawing**


Item	Part name	Material
100	Casing	Ductile iron / Tefzel
100U	Volute insert	Carbon-filled Tefzel
101	Impeller assembly	Tefzel
260 <sup>1</sup>	Bearing spider	Tefzel / silicon carbide
122A	Stationary shaft	Silicon carbide
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial	PTFE
178S <sup>1</sup>	Key – impeller to radial bearings	Tefzel
178Y	Key – motor to drive carrier	Steel
197B <sup>1</sup>	Bearing – radial	Standard: carbon Optional: silicon carbide Optional: DryGuard® silicon carbide
197C <sup>1</sup>	Bearing – reverse thrust	Carbon-filled PTFE
197D <sup>1</sup>	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
222L	Setscrew	303 SS
228	Frame – close coupled (NEMA)	Cast iron
356A	Hex capscrew – clamp ring to backplate	304 SS
360W <sup>1</sup>	Gasket – support to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – frame to clamp ring	304 SS
372V	Hex capscrew – backplate to casing	304 SS
412M <sup>1</sup>	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
412V <sup>1</sup>	O-ring – backplate	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
444	Backplate	Ductile iron / Tefzel
492A	Plug – access hole	Steel
740B	Drive magnet assembly	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester
811	Cover – casing drain	Carbon steel
811A	Cover – casing fill	Carbon steel
811B	Gasket – casing drain	Non-asbestos packing
811C	Gasket – casing fill	Non-asbestos packing
811D	Hex capscrew – drain cover	304 SS

Item	Part name	Material
<sup>1</sup> Recommended spare parts		


Item	Part name	Material
228	Frame – close coupled (IEC)	Ductile iron
222L	Setscrew	304 SS
371	Hex capscrew – motor to frame	Carbon steel
388T	Hex capscrew – adapter to frame <sup>1</sup>	Carbon steel
408A	Plug – drain	Carbon steel
492A	Plug – access hole	Carbon steel
503	Ring – adapter <sup>1</sup>	Cast iron
742B	Ring – centering <sup>2</sup>	Carbon steel
<sup>1</sup> Used with motor frame 132 and 160 only. <sup>2</sup> Used with motor frames 80 and 90 only.		

## 8.10 V3298 close-coupled S group pump in sizes 1-1/2 x 2 - 6, 2 x 3 - 6, 1-1/2 x 2 - 8 and M group size 1-1/2 x 2 - 10

V3298 S and M group drawing, with NEMA motor








**Figure 102: Drain detail**

**V3298 S and M group drawing, with IEC motor**



**V3298 close-coupled S and M group parts list**

Item	Part name	Material
100	Casing	Ductile iron / Tefzel
101	Impeller assembly	Tefzel
260	Bearing spider	Tefzel / silicon carbide
122A	Stationary shaft	Silicon carbide
141C	Clamp ring	Ductile iron
157A	Bearing spacer – radial	PTFE
178S	Key – impeller to radial bearings	Tefzel
178Y	Key – motor to magnet assembly	Steel
197B	Bearing – radial	Standard: carbon Optional: silicon carbide Optional: DryGuard® silicon carbide
197C	Bearing – reverse thrust	Carbon-filled PTFE


8.10 V3298 close-coupled S group pump in sizes 1-1/2 x 2 - 6, 2 x 3 - 6, 1-1/2 x 2 - 8 and M group size 1-1/2 x 2 - 10

Item	Part name	Material
197D	Bearing – impeller thrust	Standard: carbon-filled PTFE Optional: silicon carbide Optional: DryGuard® silicon carbide
203	Wear ring – rear	Carbon-filled PTFE
222L	Setscrew	303 SS
228	Frame – close coupled (NEMA)	Cast iron
351G	Gasket – casing drain	Non-asbestos packing
356A	Hex capscrew – clamp ring to casing	304 SS
358	Cover – drain	Steel
360W	Gasket – support to clamp ring	Aramid fibers with EPDM
370B	Hex capscrew – backplate to clamp ring	304 SS
412M	O-ring – containment shell	Standard: Viton Optional: EPDM Optional: PTFE-encapsulated Viton Optional: Chemraz 505 Optional: Kalrez 4079
426A	Hex capscrew – drain cover	304 SS
492A	Plug – access hole	Steel
740B	Drive magnet assembly	Cast iron / neodymium iron
750	Containment shell	Tefzel / fiber-reinforced vinylester


Item	Part name	Material
228	Frame – close coupled (IEC)	Ductile iron
222L	Setscrew	304 SS
371	Hex capscrew – motor to frame	Carbon steel
388T	Hex capscrew – adapter to frame <sup>1</sup>	Carbon steel
408A	Plug – drain	Carbon steel
492A	Plug – access hole	Carbon steel
503	Ring ,– adapter <sup>1</sup>	Cast iron
742B	Ring – centering <sup>2</sup>	Carbon steel
<sup>1</sup> Used with motor frame 132 and 160 only. <sup>2</sup> Used with motor frames 80 and 90 only.		

# 8.11 Interchangeability drawings


## 3298 XS group interchangeability




**3298 S group interchangeability**




**3298 M group interchangeability**




**3298 M group interchangeability – size 1½ x 3-8 only**




**3298 L group interchangeability**



**SP3298 S group interchangeability**




**V3298 S group interchangeability**






**V3298 M group interchangeability**




**8.12 Hydraulic coverage charts**

**3298 charts**


**2-Pole Operating Speed**




### 4-Pole Operating Speed




### SP3298 charts






**V3298 charts**



## 8.12 Hydraulic coverage charts



# 9 Other Relevant Documentation or Manuals

## 9.1 For additional documentation

For any other relevant documentation or manuals, contact your ITT representative.

# 10 Local ITT Contacts

## 10.1 Regional offices

Region	Address	Telephone	Fax
North America (Headquarters)	ITT - Goulds Pumps 240 Fall Street Seneca Falls, NY 13148 USA	+1 315-568-2811	+1 315-568-2418
Houston office	12510 Sugar Ridge Boulevard Stafford, TX 77477 USA	+1 281-504-6300	+1 281-504-6399
Los Angeles	Vertical Products Operation 3951 Capitol Avenue City of Industry, CA 90601-1734 USA	+1 562-949-2113	+1 562-695-8523
Asia Pacific	ITT Fluid Technology Asia Pte Ltd 1 Jalan Kilang Timor #04-06 Singapore 159303	+65 627-63693	+65 627-63685
Asia Pacific	ITT Goulds Pumps Ltd 35, Oksansandan-ro Oksan-myeon, Heungdeok-gu, Cheongju-si, Chungcheongbuk-do 28101, Rep. of KOREA	+82 234444202	
Europe	ITT - Goulds Pumps Millwey Rise Industrial Estate Axminster, Devon, England EX13 5HU	+44 1297-639100	+44 1297-630476
Latin America	ITT - Goulds Pumps Camino La Colina # 1448 Condominio Industrial El Rosal Huechuraba Santiago 8580000 Chile	+562 544-7000	+562 544-7001
Middle East and Africa	ITT - Goulds Pumps Achileos Kyrou 4 Neo Psychiko 115 25 Athens Greece	+30 210-677-0770	+30 210-677-5642

**Visit our website for the latest version of  
this document and more information:**  
[www.gouldspumps.com](http://www.gouldspumps.com)



ITT Goulds Pumps, Inc.  
240 Fall Street  
Seneca Falls, NY 13148  
USA

**Form IOM.3298.en-US.2022-11**

©2022 ITT Inc.  
The original instruction is in English. All non-English instructions are translations of the original instruction.